

# Instructions



## Dome Cover

Model No. **WV-CW6SA**

Before attempting to connect or operate this product, please read these instructions carefully and save this manual for future use.

The model number is abbreviated in some descriptions in this manual.


## Features

The WV-CW6SA is the smoke type dome cover dedicated to our cameras. Contact your dealer for the cameras compliant with this product.

## Installations

Please read the operating instructions for the camera as well.


1. Detach the enclosure from the camera body by referring to the operating instructions of the camera.
2. Detach the dome cover from the enclosure by removing the fixing screws. (Refer to the illustration described beside step 5.)
3. Detach the protection film from the smoke dome cover. (Be careful not to scratch the dome.)
4. Attach the smoke dome cover to the enclosure and fasten the fixing screws removed in step 2. (Refer to the illustration described beside step 5.)



2. Detach the dome cover from the enclosure by removing the fixing screws. (Refer to the illustration described beside step 5.)

- When the camera in use is SW150 Series, be sure to seal the enclosure with a waterproof gasket. In addition, make sure that no twist or deformation is found and no dust is sticking on the gasket.

5. Attach the enclosure to the camera body by referring to the operating instructions of the camera.



## Specifications

Ambient temperature	-30 °C to +50 °C {-22 °F - +122 °F}
Weight	approx. 15 g {0.003 lbs.}
Dimensions	72 mm (W) x 37 mm (H) x 67 mm (D) {2-27/32 inches (W) x 1-15/32 inches (H) x 2-5/8 inches (D)} (Dome diameter 54 mm {2-1/8 inches})

## Standard Accessories

Instructions (this document).....	1 pc.
Instructions (Japanese).....	1 pc.

### For U.S. and Canada:

i-PRO Americas Inc.

### For Europe and other countries:

i-PRO EMEA B.V.

<https://www.i-pro.com/>