

# CORRIGENDA

Operating Instructions contain misdescription. Please refer to the following for the correction.

## 11.5 Configure the settings relating to the camera operations [Cam. Function] [Extra optical zoom]

| Wrong   | Right   |
|---|---|
| <p><b>[Extra optical zoom]</b><br/>Select the <u>extra</u> optical zoom setting from the following.</p> <ul style="list-style-type: none"> <li>• <b>On (Max X90):</b> Images can be zoomed in on with the optical zoom (1x - 30x) and the <u>extra</u> optical zoom (higher zoom factors, up to <u>90x</u>).</li> <li>• <b>Off (Max X30):</b> Does not use the <u>extra</u> optical zoom.</li> <li>• <b>Default:</b> On (Max X90)</li> </ul> <p><b>About <u>extra</u> optical zoom</b><br/>Among approx. 2.07 megapixel image capture area of the MOS image sensor, the central part of approx. <u>0.23</u> megapixels is extracted for shooting. That enables the shooting with a higher zooming effect. When the image capture size of <u>640x360</u> or less is applied, the zoom factor can be adjusted up to <u>90x</u>.</p> | <p><b>[HD Extra optical zoom]</b><br/>Select the <u>HD Extra</u> optical zoom setting from the following.</p> <ul style="list-style-type: none"> <li>• <b>On (Max X45):</b> Images can be zoomed in on with the optical zoom (1x - 30x) and the <u>HD Extra</u> optical zoom (higher zoom factors, up to <u>45x</u>).</li> <li>• <b>Off (Max X30):</b> Does not use the <u>HD Extra</u> optical zoom.</li> <li>• <b>Default:</b> On (Max X45)</li> </ul> <p><b>About <u>HD Extra</u> optical zoom</b><br/>Among approx. 2.07 megapixel image capture area of the MOS image sensor, the central part of approx. <u>0.92</u> megapixels is extracted for shooting. That enables the shooting with a higher zooming effect. When the image capture size of <u>1280x720</u> or less is applied, the zoom factor can be adjusted up to <u>45x</u>.</p> |

## [Digital zoom]

| Wrong   | Right  |
|---|--|
| <p><b>[Digital zoom]</b><br/>Select the digital zoom setting from the following.</p> <ul style="list-style-type: none"> <li>• <b>On (Max X1080):</b> Images can be zoomed in on with the optical zoom (1x - 30x), <u>extra</u> optical zoom (up to <u>90x</u>) and the electronic zoom (higher zoom factors, up to 1080x).</li> <li>• <b>Off:</b> Does not use the digital zoom.</li> <li>• <b>Default:</b> Off</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• When “On (Max X1080)” is selected, digital zooming will stop when the zoom factor has reached <u>90x</u>.</li> <li>• When the zoom factor is <u>90x</u> or more, the setting of the preset positions will become unavailable.</li> </ul> | <p><b>[Digital zoom]</b><br/>Select the digital zoom setting from the following.</p> <ul style="list-style-type: none"> <li>• <b>On (Max X1080):</b> Images can be zoomed in on with the optical zoom (1x - 30x), <u>HD Extra</u> optical zoom (up to <u>45x</u>) and the electronic zoom (higher zoom factors, up to 1080x).</li> <li>• <b>Off:</b> Does not use the digital zoom.</li> <li>• <b>Default:</b> Off</li> </ul> <p><b>Note</b></p> <ul style="list-style-type: none"> <li>• When “On (Max X1080)” is selected, digital zooming will stop when the zoom factor has reached <u>45x</u>.</li> <li>• When the zoom factor is <u>45x</u> or more, the setting of the preset positions will become unavailable.</li> </ul> |

## 11.6.3 Configure the settings relating to the preset positions (“Preset position” setup menu)

### **IMPORTANT**

| Wrong  | Right  |
|--|--|
| <ul style="list-style-type: none"> <li>• When the zoom factor is <u>90x</u> or more, the setting of the preset positions will become unavailable.</li> </ul> | <ul style="list-style-type: none"> <li>• When the zoom factor is <u>45x</u> or more, the setting of the preset positions will become unavailable.</li> </ul> |

## 11.6.4 Configure the settings relating to the auto pan function (“Auto pan” setup menu)

### [Speed]

### **Note**

| Wrong  | Right  |
|--|--|
| <ul style="list-style-type: none"> <li>• Even when the selected zoom factor is higher than <u>90x</u>, the camera will start panning with <u>90x</u> zoom factor.</li> </ul> | <ul style="list-style-type: none"> <li>• Even when the selected zoom factor is higher than <u>45x</u>, the camera will start panning with <u>45x</u> zoom factor.</li> </ul> |