

## CORRIGENDA

Important Information contain misdescriptions. Refer to the following table and confirm the descriptions that are corrected.

■ Specifications - Camera - Super Dynamic: <WV-X4170 / WV-X4171 / WV-X4571L / WV-X4571LM>

Incorrect		Correct	
Super Dynamic:	On / Off, the level can be set in the range of 0 to 31. *When "On" is selected for "Super Dynamic(SD)", the frame rate is restricted to a maximum of 15fps.	Dynamic range mode:	On(Wide dynamic range)/On(Super Dynamic)/Off, the level can be set in the range of 0 to 31. *When "On(Super Dynamic)" is selected for "Dynamic range mode ", the frame rate is restricted to a maximum of 15fps.

■ Specifications - Camera - Dynamic range: <WV-X4170 / WV-X4171 / WV-X4571L / WV-X4571LM>

Incorrect	Correct
108 dB typ. (Super Dynamic: On, level: 31)	108 dB typ. (Dynamic range mode: On(Super Dynamic), level: 31)

■ Specifications - Camera - Back light compensation (BLC)/High light compensation(HLC): <WV-X4170 / WV-X4171 / WV-X4571L / WV-X4571LM>

Incorrect	Correct
BLC/ HLC/ Off, the level can be set in the range of 0 to 31. (only when Super Dynamic/ Intelligent auto: Off)	BLC/ HLC/ Off, the level can be set in the range of 0 to 31. (only when Dynamic range mode/ Intelligent auto: Off)

Operating Instructions contain a misdescription. Refer to the following table and confirm the description that is corrected.

■ 2.5.5.3 Adjusting back focus – [Focus]

Incorrect	Correct
<ul style="list-style-type: none"> <li>[Reset]: Click this button to reset the focus to the default.</li> </ul>	<ul style="list-style-type: none"> <li>[Reset]: Click this button to reset the focus to the default. The focus of both color images and monochrome images are reset to the default values.</li> </ul>