

WV-X1551LN/ WV-X2551LN/ WV-X2251L/ WV-X1571LN/ WV-X2571LN/ WV-X2271L

WV-X1551LN WV-X2551LN WV-X2251L	WV-X1571LN WV-X2571LN WV-X2271L	Priority Rank Level	Priority Rank Level				Contents		
			A	B	C	U	Issue (Phenomenon)	Occurrence condition	Correspondence
Ver1.00 (4.60.03) July, '20		-					First production		
Ver1.11 (4.60.03) Oct., '20		C				x	-		Supports version 1.20 of WV-XAE200W Note: When the installed version of WV-XAE200W is 1.00, the camera displays "1.00 (Version error)". (Displayed in [Ext. software] page> [Software mng.] tab> [Software version])
					x		Live image or recorded images of the stream for AI Privacy guard recording partially have green tint. (Occurrence frequency: Rare)	When either of below changes is made: - Register the camera on a recorder - Change the images capture size of "Stream(1)"	Fixed.
					x		The camera may reboot. (Occurrence frequency: Rare)	-	Fixed.
-	Ver1.20 (4.60.03) Oct., '20	-					First production		
Ver1.30 (4.60.04) Nov., '20	Ver1.30 (4.60.04) Nov., '20	C				x	-		Added the "Control log" tab to the [Ext. software] window in the camera setting.
						x	-		Added "Ext. software mode" to the [SD memory card] tab to enable the extension software to use SD memory card.
				x			Cannot upgrade an extension software larger than 25 Mbyte. (Occurrence frequency: High)	-	Expanded the data size of one extension software from 25 Mbyte to 100 Mbyte.
				x			Motion blur appears on moving subjects such as pedestrians.	Under low illuminance	Improved the visibility by reducing motion blur.
			x			The contrast of bright areas on the backlit image is low.	When "Super Dynamic(SD)" is ON.	Improved the image quality to enhance the contrast.	
	Already supported in Ver.1.20					x	AI frames appear in red instead of the correct color green. (Occurrence frequency: High)	Under all of the below conditions: - WV-XAE200W is installed on the camera - "With detected object information (AI frame information)" is selected for [Additional information type] - The schedule for WV-XAE200W has been once switched to "Off" in [Operation content], and then switched back to "Detection program 1" or "Detection program 2"	Fixed.
				x	The position of a detection frame on the live image may be shifted from the one on the setup menu. (Occurrence frequency: Low)	Under both of the below conditions: - WV-XAE200W is installed on the camera - "90 °" or "270 °" is selected for "Image rotation" in the camera setting	Fixed.		