

WJ-NX200K, WJ-NX200K/G

New functions and revisions (Software V4.50)

The recorder will be able to provide the following new functions by updating the software.

It also contains the latest information related to the Operating Instructions.

Details on the new functions and revisions	Reference pages
<p>Addition of description Restrictions when using this product When using AI privacy guard recording</p> <ul style="list-style-type: none"> ● Depending on the camera, the upper limit of the frame rate differs when AI privacy guard is set. For details, please refer to the operating instructions of the camera. 	<p>Page 10 of PGQQ1325NA</p>
<p>Changes of description Restrictions when using this product When registering the network camera U series</p> <ul style="list-style-type: none"> ● Cameras without "A" in the part number do not support H.264 function. Do not set H.264 as the compression method. ● Cameras without "A" in the part number do not support the security extension function. Do not set the connection method to HTTPS as the security settings between the recorder and the camera. ● To set the recording frame rate to 30 ips/25 ips, select "(30IPS)" in the camera registration options. ● If the frame rate of recording is set to 30 ips/25 ips, it may not be possible to display on multiscreen depending on the setting of image capture size, the presence of sub-monitor display, and the presence of re-encoding transmission. Also, sub-stream recording is not included. ● To set the recording frame rate to 30 ips/25 ips for cameras without "A" in the part number, select "(30 IPS)" in the camera registration options. Meanwhile, depending on the resolution settings, sub-monitor display or re-encoded distribution, it may not be possible to display on multiple screens. In addition, the sub-stream recording will not be included. ● Smart coding (GOP control) settings cannot be used depending on the settings of the camera. ● U series cameras refer to the following product numbers [as of August 2021]. WV-U1130, WV-U1132, WV-U1142, WV-U1532L, WV-U1542L, WV-U2130L, WV-U2132L, WV-U2140L, WV-U2142L, WV-U2530L, WV-U2532L, WV-U2540L, WV-U2542L, WV-U1130A, WV-U1132A, WV-U1142A, WV-U1532LA, WV-U1542LA, WV-U2130LA, WV-U2132LA, WV-U2140LA, WV-U2142LA, WV-U2530LA, WV-U2532LA, WV-U2540LA, WV-U2542LA 	<p>Page 16 of PGQQ1325NA</p>
<p>Description addition change Language tab [Language] 日本語/ English/ Français/ Español/ Deutsch/ Italiano/ Русский/ Português/ ไทย/ 簡體中文/ 繁體中文 Default: English</p>	<p>Page 11</p>

Details on the new functions and revisions

Reference pages

Changes to the screen [Extension software alarm]
 Addition of setting change items (1~4)

Page 12 of PGQQ1325NA



Changes of description [Message ID]

Select alarm message ID to be received as extension software alarms 1 to 8 in decimal number (000 to 255).

Note:

- 50, 51, 52, and 56 cannot be set.

List of setting items Changes of description

Date/Language > Language

Page 77

Setting item	Available range	Default	Remarks
Language	日本語/ English/ Français/ Español/ Deutsch/ Italiano/ Русский/ Português/ ไทย/ 简体中文/繁體中文 (Web browser: Japanese/ English/ Français/ Español/ Deutsch/ Italiano/ Russian/ Português/ Thai/ Simplified Chinese, Traditional Chinese)	English (Web browser: English)	©

List of setting items Changes of description

REC & event > Advanced setup

Page 14 of PGQQ1325NA

Setting item	Available range	Default	Remarks
Extension software alarm	Message ID	000 to 255,---	No.1 : 50, No.2 : 51, No.3 : 52, No.4 : 56, No.5-8 : ---

Changes of description Uninstall the viewer software Step 2

Page 182

Select "WebVideo ActiveX NX 7" (the program to be deleted) from the presently installed programs, and then right-click on it.

Changes of description How to use the viewer software

Page 183

Select "NX_Viewer" from the start menu ("All programs" — "Panasonic" — "Network Disk Recorder" — "NX_Viewer") or double-click the NX_Viewer icon on the desktop.

Details on the new functions and revisions			Reference pages					
Changes of description Troubleshooting			Page 203					
<table border="1"> <thead> <tr> <th>Symptom</th> <th>Cause/solution</th> <th>Reference</th> </tr> </thead> <tbody> <tr> <td> The following message is displayed on the information bar. "This site might require the following ActiveX control: 'wvasetupnx.exe' from '<u>Panasonic i-PRO Sensing Solutions Co., Ltd</u>'. Click here to install..." </td> <td> <ul style="list-style-type: none"> Click the information bar and select "Install ActiveX Control...". Click the "Install" button on the displayed "Security Warning" window. </td> <td>—</td> </tr> </tbody> </table>	Symptom	Cause/solution		Reference	The following message is displayed on the information bar. "This site might require the following ActiveX control: 'wvasetupnx.exe' from ' <u>Panasonic i-PRO Sensing Solutions Co., Ltd</u> '. Click here to install..."	<ul style="list-style-type: none"> Click the information bar and select "Install ActiveX Control...". Click the "Install" button on the displayed "Security Warning" window. 	—	
Symptom	Cause/solution	Reference						
The following message is displayed on the information bar. "This site might require the following ActiveX control: 'wvasetupnx.exe' from ' <u>Panasonic i-PRO Sensing Solutions Co., Ltd</u> '. Click here to install..."	<ul style="list-style-type: none"> Click the information bar and select "Install ActiveX Control...". Click the "Install" button on the displayed "Security Warning" window. 	—						