

Control Commands

Model No. PT-RZ570

PT-RZ575



- Please refer to the Service Manual or Operating Instructions for the serial command format, limitations, connection and other details.
- シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルのテクニカルガイドまたは取扱説明書をご覧ください。

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575	
BASIC OPERATION REMOTE CONTROL	POWER	ON		PON	QPW	001	✓	✓	
		OFF (STANDBY)		POF		000	✓	✓	
	VOLUME	UP		AUU			✓	✓	
		DOWN		AUD			✓	✓	
	INPUT SELECT	COMPUTER1			IIS: RG1	QIN	RG1	✓	✓
		COMPUTER2			IIS: RG2		RG2	✓	✓
		VIDEO			IIS: VI D		VI D	✓	✓
		DVI			IIS: DVI		DVI	✓	✓
		HDMI1			IIS: HD1		HD1	✓	✓
		HDMI2			IIS: HD2		HD2	✓	✓
		DIGITAL LINK			IIS: DL1		DL1	✓	✓
	INPUT SELECT (DIGITAL LINK)	COMPUTER1			IIS: DL1: PC1	QIN	DL1: PC1	✓	✓
		COMPUTER2			IIS: DL1: PC2		DL1: PC2	✓	✓
		VIDEO			IIS: DL1: VI D		DL1: VI D	✓	✓
		HDMI1			IIS: DL1: HD1		DL1: HD1	✓	✓
		HDMI2			IIS: DL1: HD2		DL1: HD2	✓	✓
	FREEZE	OFF			OFZ: 0	QFZ	0	✓	✓
		ON			OFZ: 1		1	✓	✓
	MENU KEY			OMN			✓	✓	
	RETURN KEY			OBK			✓	✓	
	ENTER KEY			OEN			✓	✓	
	UP KEY			OCU			✓	✓	
	DOWN KEY			OCD			✓	✓	
	LEFT KEY			OCL			✓	✓	
	RIGHT KEY			OCR			✓	✓	
	DEFAULT KEY			OST			✓	✓	
	AUTO SETUP KEY			OAS			✓	✓	
	SHUTTER	OFF			OSH: 0	QSH	0	✓	✓
		ON			OSH: 1		1	✓	✓
	SHUTTER(Toggle)	OFF			OSH	QSH	0	✓	✓
		ON					1	✓	✓
	FUNCTION KEY			FC1			✓	✓	
	SYSTEM SELCTOR KEY			OSL			✓	✓	
	ASPECT KEY			VS1			✓	✓	
	ECO			OEC			✓	✓	
	NUMERIC KEY	0			ONK: 0			✓	✓
		1			ONK: 1			✓	✓
		2			ONK: 2			✓	✓
		3			ONK: 3			✓	✓
		4			ONK: 4			✓	✓
		5			ONK: 5			✓	✓
		6			ONK: 6			✓	✓
		7			ONK: 7			✓	✓
		8			ONK: 8			✓	✓
	9			ONK: 9			✓	✓	
LENS HOME POSITION	EXECUTE			VXX: LNSI 1=+00001			✓	✓	
LENS SHIFT-HORIZONTAL	SLOW+			VXX: LNSI 2=+00000			✓	✓	
	SLOW-			VXX: LNSI 2=+00001			✓	✓	
	NORMAL+			VXX: LNSI 2=+00100			✓	✓	
	NORMAL-			VXX: LNSI 2=+00101			✓	✓	
	FAST+			VXX: LNSI 2=+00200			✓	✓	
	FAST-			VXX: LNSI 2=+00201			✓	✓	
LENS SHIFT-VERTICAL	SLOW+			VXX: LNSI 3=+00000			✓	✓	
	SLOW-			VXX: LNSI 3=+00001			✓	✓	
	NORMAL+			VXX: LNSI 3=+00100			✓	✓	
	NORMAL-			VXX: LNSI 3=+00101			✓	✓	
	FAST+			VXX: LNSI 3=+00200			✓	✓	
	FAST-			VXX: LNSI 3=+00201			✓	✓	
LENS FOCUS	SLOW+			VXX: LNSI 4=+00000			✓	✓	
	SLOW-			VXX: LNSI 4=+00001			✓	✓	
	NORMAL+			VXX: LNSI 4=+00100			✓	✓	
	NORMAL-			VXX: LNSI 4=+00101			✓	✓	
	FAST+			VXX: LNSI 4=+00200			✓	✓	
	FAST-			VXX: LNSI 4=+00201			✓	✓	
STATUS KEY			STS			✓	✓		
LENS FOCUS KEY			OLF			✓	✓		
LENS SHIFT KEY			OLH			✓	✓		
DIGITAL LINK KEY			DLK			✓	✓		
INPUT MENU KEY			I PT			✓	✓		
SCREEN ADJUSTMENT			OSA			✓	✓		
AUDIO MUTE	OFF			AMT: 0	QMT	0	✓	✓	
	ON			AMT: 1		1	✓	✓	
PICTURE MODE	DYNAMIC			VPM: DYN	QPM	DYN	✓	✓	
	NATURAL			VPM: NAT		NAT	✓	✓	
	STANDARD			VPM: STD		STD	✓	✓	
	CINEMA			VPM: CI N		CI N	✓	✓	
	GRAPHIC			VPM: GRA		GRA	✓	✓	
	DICOM SIM.			VPM: DI C		DI C	✓	✓	
	REC709			VPM: 709		709	✓	✓	
CONTRAST	+1			VCN: 001	QVR	001	✓	✓	
	+63			VCN: 063		063	✓	✓	
BRIGHTNESS	+1			VBR: 001	QVB	001	✓	✓	
	+63			VBR: 063		063	✓	✓	
COLOR	+1			VCO: 001	QVC	001	✓	✓	
	+63			VCO: 063		063	✓	✓	
TINT	+1			VTN: 001	QVT	001	✓	✓	
	+63			VTN: 063		063	✓	✓	
SHARPNESS	0			VSR: 000	QVS	000	✓	✓	
	15			VSR: 015		015	✓	✓	
WHITE GAIN	0			VWH: 00	QWH	00	✓	✓	
	10			VWH: 10		10	✓	✓	
COLOR TEMPERATURE	LOW			OTE: 0	QTE	0	✓	✓	
	HIGH			OTE: 2		2	✓	✓	
	USER1(USER)			OTE: 04		4	✓	✓	
	DEFAULT			OTE: 10		10	✓	✓	
COLOR TEMP-NAME SETTING USER1	COLORTEMP1			VXX: NCGS1=COLORTEMP1	QVX: NCGS1	NCGS1=COLORTEMP1	✓	✓	
COLOR TEMP-NAME CLEAR USER1	COLORTEMP1			VXX: NCLI 1=+00000			✓	✓	
WHITE BALANCE LOW-RED	-127			VOR: 001	QOR	001	✓	✓	
WHITE BALANCE LOW-GREEN	-127			VOG: 001	QOG	001	✓	✓	
	+127			VOG: 255		255	✓	✓	
WHITE BALANCE LOW-BLUE	-127			VOB: 001	QOB	001	✓	✓	
	+127			VOB: 255		255	✓	✓	
WHITE BALANCE HIGH-RED	0			VHR: 000	QHR	000	✓	✓	
	+255			VHR: 255		255	✓	✓	
WHITE BALANCE HIGH-GREEN	0			VHG: 000	QHG	000	✓	✓	
	+255			VHG: 255		255	✓	✓	
WHITE BALANCE HIGH-BLUE	0			VHB: 000	QHB	000	✓	✓	
	+255			VHB: 255		255	✓	✓	
GAMMA	1.8			VGA: 1. 8	QGA	1. 8	✓	✓	
	2.0			VGA: 2. 0		2. 0	✓	✓	
	2.2			VGA: 2. 2		2. 2	✓	✓	
	DEFAULT			VGA: DEF		DEF	✓	✓	
DAYLIGHT VIEW	OFF			VXX: DLVI 0=+00000	QVX: DLVI 0	DLVI 0=+00000	✓	✓	
	AUTO			VXX: DLVI 0=+00001		DLVI 0=+00001	✓	✓	

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575	
	NOISE REDUCTION	1		VXX: DLVI 0=+00002		DLVI 0=+00002	✓	✓	
		2		VXX: DLVI 0=+00003		DLVI 0=+00003	✓	✓	
		3		VXX: DLVI 0=+00004		DLVI 0=+00004	✓	✓	
	DYNAMIC CONTRAST/IRIS	OFF		VNS: 0	QNS	0	✓	✓	
		1		VNS: 1		1	✓	✓	
		2		VNS: 2		2	✓	✓	
	TV-SYSTEM	AUTO1		VSG: AT1	QSG	AT1	✓	✓	
		NTSC		VSG: NTS		NTS	✓	✓	
	SYSTEM SELECTOR RGB(VGA/480P)	NTSC4.43		VSG: N44		N44	✓	✓	
		PAL		VSG: PAL		PAL	✓	✓	
		PAL-M		VSG: PAM		PAM	✓	✓	
		PAL-N		VSG: PAN		PAN	✓	✓	
		PAL60		VSG: P60		P60	✓	✓	
		SECAM		VSG: SEC		SEC	✓	✓	
	SYSTEM SELECTOR RGB(Other)/DVI/SLOT-DVI	VGA60		ORF: 0	QRF	0	✓	✓	
		480P(YCbCr)		ORF: 1		1	✓	✓	
		480p(RGB)		ORF: 3		3	✓	✓	
	SYSTEM SELECTOR HDMI/DIGITAL LINK/SLOT-HDMI	RGB		ORF: 0	QRF	0	✓	✓	
		YPbPr		ORF: 1		1	✓	✓	
		AUTO		ORF: 2		2	✓	✓	
	POSITION	GEOMETRY	OFF		VXX: GMMI 0=+00000	QVX: GMMI 0	GMMI 0=+00000	✓	✓
			KEYSTONE		VXX: GMMI 0=+00001		GMMI 0=+00001	✓	✓
			CURVED		VXX: GMMI 0=+00002		GMMI 0=+00002	✓	✓
			PC-1		VXX: GMMI 0=+00003		GMMI 0=+00003	✓	✓
PC-2				VXX: GMMI 0=+00004		GMMI 0=+00004	✓	✓	
PC-3				VXX: GMMI 0=+00005		GMMI 0=+00005	✓	✓	
GEOMETRY-KEYSTONE- LENS THROW RATIO		CORNER-CORRECTION		VXX: GMMI 0=+00010		GMMI 0=+00010	✓	✓	
		0.7	0.1 step	VXX: GMKSO=+00. 7	QVX: GMKSO	GMKSO=+00. 7	✓	✓	
GEOMETRY-KEYSTONE- VERTICAL BALANCE		16.5		VXX: GMKSO=+16. 5		GMKSO=+16. 5	✓	✓	
		-60		VXX: GMKI 4=-00060	QVX: GMKI 4	GMKI 4=-00060	✓	✓	
GEOMETRY-KEYSTONE- HORIZONTAL BALANCE		+60		VXX: GMKI 4=+00060		GMKI 4=+00060	✓	✓	
		-30		VXX: GMKI 7=-00030	QVX: GMKI 7	GMKI 7=-00030	✓	✓	
GEOMETRY-KEYSTONE- VERTICAL KEYSTONE		+30		VXX: GMKI 7=+00030		GMKI 7=+00030	✓	✓	
		-40.0 (-45.0)*	0.2 step	VXX: GMKS8=-40. 0	QVX: GMKS8	GMKS8=-40. 0	✓	✓	
GEOMETRY-KEYSTONE- HORIZONTAL KEYSTONE		+40.0 (+45.0)*		VXX: GMKS8=+40. 0		GMKS8=+40. 0	✓	✓	
		-15.0 (-40.0)*	0.2 step	VXX: GMKS9=-15. 0	QVX: GMKS9	GMKS9=-15. 0	✓	✓	
GEOMETRY-CURVED-LENS THROW RATIO		+15.0 (+40.0)*		VXX: GMKS9=+15. 0		GMKS9=+15. 0	✓	✓	
		0.7	0.1 step	VXX: GMCSO=+00. 7	QVX: GMCSO	GMCSO=+00. 7	✓	✓	
GEOMETRY-CURVED- VERTICAL ARC		16.5		VXX: GMCSO=+16. 5		GMCSO=+16. 5	✓	✓	
		-50 (-100)*		VXX: GMCI 3=-00050	QVX: GMCI 3	GMCI 3=-00050	✓	✓	
GEOMETRY-CURVED- HORIZONTAL ARC		+50 (+100)*		VXX: GMCI 3=+00050		GMCI 3=+00050	✓	✓	
		-50 (-100)*		VXX: GMCI 7=-00050	QVX: GMCI 7	GMCI 7=-00050	✓	✓	
GEOMETRY-CURVED- VERTICAL BALANCE		+50 (+100)*		VXX: GMCI 7=+00050		GMCI 7=+00050	✓	✓	
		-60		VXX: GMCI 2=-00060	QVX: GMCI 2	GMCI 2=-00060	✓	✓	
GEOMETRY-CURVED- HORIZONTAL BALANCE	+60		VXX: GMCI 2=+00060		GMCI 2=+00060	✓	✓		
	-30		VXX: GMCI 6=-00030	QVX: GMCI 6	GMCI 6=-00030	✓	✓		
GEOMETRY-CURVED- VERTICAL KEYSTONE	+30		VXX: GMCI 6=+00030		GMCI 6=+00030	✓	✓		
	-40.0 (-45.0)*	0.2 step	VXX: GMCS8=-40. 0	QVX: GMCS8	GMCS8=-40. 0	✓	✓		
GEOMETRY-CURVED- HORIZONTAL KEYSTONE	+40.0 (+45.0)*		VXX: GMCS8=+40. 0		GMCS8=+40. 0	✓	✓		
	-15.0 (-40.0)*	0.2 step	VXX: GMCS9=-15. 0	QVX: GMCS9	GMCS9=-15. 0	✓	✓		
GEOMETRY-CURVED- MAINTAIN ASPECT RATIO	+15.0 (+40.0)*		VXX: GMCS9=+15. 0		GMCS9=+15. 0	✓	✓		
	OFF		VXX: GMCI A=+00000	QVX: GMCI A	GMCI A=+00000	✓	✓		
GEOMETRY-CORNER CORRECTION- UPPER LEFT(V)	ON		VXX: GMCI A=+00001		GMCI A=+00001	✓	✓		
	min.		VXX: GMFI 1=+00000	QVX: GMFI 1	GMFI 1=+00000	0	0		
GEOMETRY-CORNER CORRECTION- UPPER RIGHT(V)	max.		VXX: GMFI 1=+00300		GMFI 1=+00300	+300	+300		
	min.		VXX: GMFI 2=+00000	QVX: GMFI 2	GMFI 2=+00000	0	0		
GEOMETRY-CORNER CORRECTION- LOWER LEFT(V)	max.		VXX: GMFI 2=+00300		GMFI 2=+00300	+300	+300		
	min.		VXX: GMFI 3=-00300	QVX: GMFI 3	GMFI 3=-00300	-300	-300		
GEOMETRY-CORNER CORRECTION- LOWER RIGHT(V)	max.		VXX: GMFI 3=+00000		GMFI 3=+00000	0	0		
	min.		VXX: GMFI 4=-00300	QVX: GMFI 4	GMFI 4=-00300	-300	-300		
GEOMETRY-CORNER CORRECTION- LINEARITY(V)	max.		VXX: GMFI 4=+00000		GMFI 4=+00000	0	0		
	min.		VXX: GMFI 5=-00127	QVX: GMFI 5	GMFI 5=-00127	-127	-127		
GEOMETRY-CORNER CORRECTION- UPPER LEFT(H)	max.		VXX: GMFI 5=+00127		GMFI 5=+00127	+127	+127		
	min.		VXX: GMFI 6=+00000	QVX: GMFI 6	GMFI 6=+00000	0	0		
GEOMETRY-CORNER CORRECTION- UPPER RIGHT(H)	max.		VXX: GMFI 6=+00480		GMFI 6=+00480	+480	+480		
	min.		VXX: GMFI 7=-00480	QVX: GMFI 7	GMFI 7=-00480	-480	-480		
GEOMETRY-CORNER CORRECTION- LOWER LEFT(H)	max.		VXX: GMFI 7=+00000		GMFI 7=+00000	0	0		
	min.		VXX: GMFI 8=+00000	QVX: GMFI 8	GMFI 8=+00000	+480	+480		
GEOMETRY-CORNER CORRECTION- LOWER RIGHT(H)	max.		VXX: GMFI 8=+00480		GMFI 8=+00480	0	0		
	min.		VXX: GMFI 9=-00480	QVX: GMFI 9	GMFI 9=-00480	-480	-480		
GEOMETRY-CORNER CORRECTION- LINEARITY(H)	max.		VXX: GMFI 9=+00000		GMFI 9=+00000	0	0		
	min.		VXX: GMFI A=-00127	QVX: GMFI A	GMFI A=-00127	-127	-127		
SHIFT-HORIZONTAL	max.		VXX: GMFI A=+00127		GMFI A=+00127	+127	+127		
	0		VTH: 0000	QTH	0000	✓	✓		
SHIFT-VERTICAL	+4095		VTH: 4095		4095	✓	✓		
	0		VTV: 0000	QTV	0000	✓	✓		
CLOCK PHASE	+4094		VTV: 4094		4094	✓	✓		
	0		VCP: 000	QCP	000	✓	✓		
ASPECT	+31		VCP: 031		063	✓	✓		
	AUTO/VID AUTO/DEFAULT		VSE: 0	QSE	0	✓	✓		
	NORMAL(4:3)		VSE: 1		1	✓	✓		
	WIDE(16:9)		VSE: 2		2	✓	✓		
	NATIVE(through)		VSE: 5		5	✓	✓		
	FULL(HV FIT)		VSE: 6		6	✓	✓		
	H-FIT		VSE: 9		9	✓	✓		
	V-FIT		VSE: 10		10	✓	✓		
	ZOOM-HORIZONTAL	50		OZH: 050	QZH	050	✓	✓	
	ZOOM-VERTICAL	999		OZH: 999		999	✓	✓	
ZOOM-BOTH	50		OZV: 050	QZV	050	✓	✓		
	999		OZV: 999		999	✓	✓		
ZOOM-INTERLOCKED	50		OZO: 050	QZO	050	✓	✓		
	999		OZO: 999		999	✓	✓		
ZOOM-MODE	OFF		OZS: 0	QZS	0	✓	✓		
	ON		OZS: 1		1	✓	✓		
DIGITAL CINEMA REALITY	INTERNAL		OZT: 0	QZT	0	✓	✓		
	FULL		OZT: 1		1	✓	✓		
BLANKING-UPPER	AUTO		OPD: 0	QPD	0	✓	✓		
	OFF		OPD: 1		1	✓	✓		
BLANKING-LOWER	30p/25p FIXED		OPD: 2		2	✓	✓		
	min.		DBU: 000	QLU	000	0	0		
BLANKING-RIGHT	max.		DBU: 2398		2398	599	599		
	min.		DBB: 000	QLB	000	0	0		
BLANKING-LEFT	max.		DBB: 2398		2398	599	599		
	min.		DBR: 000	QLR	000	0	0		
INPUT RESOLUTION- TOTAL DOTS	max.		DBR: 3838		3838	959	959		
	330		DBL: 000	QLL	000	0	0		
	4095		DBL: 3838		3838	959	959		
			VTD: 0330	QTD	0330	✓	✓		
			VTD: 4095		4095	✓	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575	
ADVANCED	INPUT RESOLUTION-DISPLAY DOTS	300 4065		VDD: 0300 VDD: 4065	QDD	0300 4065	✓ ✓	✓ ✓	
	INPUT RESOLUTION-TOTAL LINES	155 2047		VTL: 0155 VTL: 2047	QTL	0155 2047	✓ ✓	✓ ✓	
	INPUT RESOLUTION-DISPLAY LINES	150 2037		VDL: 0150 VDL: 2037	QDL	0150 2037	✓ ✓	✓ ✓	
	CLAMP POSITION	1 255		VLT: 001 VLT: 255	QLT	001 255	✓ ✓	✓ ✓	
	CUSTOM MASKING *	OFF PC-1 PC-2 PC-3		VXX: MSKI 1=+00000 VXX: MSKI 1=+00001 VXX: MSKI 1=+00002 VXX: MSKI 1=+00003	QVX: MSKI 1	MSKI 1=+00000 MSKI 1=+00001 MSKI 1=+00002 MSKI 1=+00003	✓ ✓ ✓ ✓	✓ ✓ ✓ ✓	
	EDGE BLENDING	OFF ON USER		VXX: EDBI 0=+00000 VXX: EDBI 0=+00001 VXX: EDBI 0=+00002	QVX: EDBI 0	EDBI 0=+00000 EDBI 0=+00001 EDBI 0=+00002	✓ ✓ ✓	✓ ✓ ✓	
	EDGE BLENDING-UPPER ON/OFF	OFF ON		VGU: 0 VGU: 1	QGU	0 1	✓ ✓	✓ ✓	
	EDGE BLENDING-LOWER ON/OFF	OFF ON		VGB: 0 VGB: 1	QGB	0 1	✓ ✓	✓ ✓	
	EDGE BLENDING-LEFT ON/OFF	OFF ON		VGL: 0 VGL: 1	QGL	0 1	✓ ✓	✓ ✓	
	EDGE BLENDING-RIGHT ON/OFF	OFF ON		VGR: 0 VGR: 1	QGR	0 1	✓ ✓	✓ ✓	
	EDGE BLENDING-START-UPPER	<i>min.</i> <i>max.</i>		VEU: 0000 VEU: 2272	QEU	0000 2272	✓ ✓	✓ ✓	
	EDGE BLENDING-START-LOWER	<i>min.</i> <i>max.</i>		VEB: 0000 VEB: 2272	QEB	0000 2272	✓ ✓	✓ ✓	
	EDGE BLENDING-START-LEFT	<i>min.</i> <i>max.</i>		VEL: 0000 VEL: 3712	QEL	0000 3712	✓ ✓	✓ ✓	
	EDGE BLENDING-START-RIGHT	<i>min.</i> <i>max.</i>		VER: 0000 VER: 3712	QER	0000 3712	✓ ✓	✓ ✓	
	EDGE BLENDING-WIDTH-UPPER	<i>min.</i> <i>max.</i>		VXX: EUWI 0=+00000 VXX: EUWI 0=+02272	QVX: EUWI 0	EUWI 0=+00000 EUWI 0=+02272	✓ ✓	✓ ✓	
	EDGE BLENDING-WIDTH-LOWER	<i>min.</i> <i>max.</i>		VXX: EBWI 0=+00000 VXX: EBWI 0=+02272	QVX: EBWI 0	EBWI 0=+00000 EBWI 0=+02272	✓ ✓	✓ ✓	
	EDGE BLENDING-WIDTH-LEFT	<i>min.</i> <i>max.</i>		VXX: ELWI 0=+00000 VXX: ELWI 0=+03712	QVX: ELWI 0	ELWI 0=+00000 ELWI 0=+03712	✓ ✓	✓ ✓	
	EDGE BLENDING-WIDTH-RIGHT	<i>min.</i> <i>max.</i>		VXX: ERWI 0=+00000 VXX: ERWI 0=+03712	QVX: ERWI 0	ERWI 0=+00000 ERWI 0=+03712	✓ ✓	✓ ✓	
	EDGE BLENDING-MARKER-ON/OFF	OFF ON		VGM: 0 VGM: 1	QGM	0 1	✓ ✓	✓ ✓	
	EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL	0 (W,R,G,B) 255 (W,R,G,B)		VJI : 000. 000. 000. 000 VJI : 255. 255. 255. 255	QJI	000. 000. 000. 000 255. 255. 255. 255	✓ ✓	✓ ✓	
	EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL-	OFF ON		VXX: EBI I 1=+00000 VXX: EBI I 1=+00001	QVX: EBI I 1	EBI I 1=+00000 EBI I 1=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-BLACK BORDER LEVEL	0 (W,R,G,B) 255 (W,R,G,B)		VJO: 000, 000, 000, 000 VJO: 255, 255, 255, 255	QJO	000. 000. 000. 000 255. 255. 255. 255	✓ ✓	✓ ✓	
	EDGE BLENDING-BLACK BORDER LEVEL-INTERLOCKED	OFF ON		VXX: EBI I 2=+00000 VXX: EBI I 2=+00001	QVX: EBI I 2	EBI I 2=+00000 EBI I 2=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-BLACK BORDER WIDTH-UPPER	<i>min.</i> <i>max.</i>		VJU: 0000 VJU: 2272	QJU	0000 2272	0 1023	0 1023	
	EDGE BLENDING-BLACK BORDER WIDTH-LOWER	<i>min.</i> <i>max.</i>		VJB: 0000 VJB: 2272	QJB	0000 2272	0 1199	0 1199	
	EDGE BLENDING-BLACK BORDER WIDTH-LEFT	<i>min.</i> <i>max.</i>		VJL: 0000 VJL: 3712	QJL	0000 3712	0 1023	0 1023	
	EDGE BLENDING-BLACK BORDER WIDTH-RIGHT	<i>min.</i> <i>max.</i>		VJR: 0000 VJR: 3712	QJR	0000 3712	0 1919	0 1919	
	EDGE BLENDING-BLACK BORDER WIDTH-UPPER KEYSTONE AREA	<i>min.</i> <i>max.</i>		VXX: EBBI 4=-02272 VXX: EBBI 4=+02272	QVX: EBBI 4	EBBI 4=-02272 EBBI 4=+02272	-1199 1919	-1199 1919	
	EDGE BLENDING-BLACK BORDER WIDTH-LOWER KEYSTONE AREA	<i>min.</i> <i>max.</i>		VXX: EBBI 5=-02272 VXX: EBBI 5=+02272	QVX: EBBI 5	EBBI 5=-02272 EBBI 5=+02272	-1199 1919	-1199 1919	
	EDGE BLENDING-BLACK BORDER WIDTH-LEFT KEYSTONE AREA	<i>min.</i> <i>max.</i>		VXX: EBBI 6=-03712 VXX: EBBI 6=+03712	QVX: EBBI 6	EBBI 6=-03712 EBBI 6=+03712	-1199 1919	-1199 1919	
	EDGE BLENDING-BLACK BORDER WIDTH-RIGHT KEYSTONE AREA	<i>min.</i> <i>max.</i>		VXX: EBBI 7=-03712 VXX: EBBI 7=+03712	QVX: EBBI 7	EBBI 7=-03712 EBBI 7=+03712	-1199 1919	-1199 1919	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER	0 (W,R,G,B) 255 (W,R,G,B)		VXX: EBBS0=000, 000, 000, 000 VXX: EBBS0=255, 255, 255, 255	QVX: EBBS0	EBBS0=000, 000, 000, 000 EBBS0=255, 255, 255, 255	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER	0 (W,R,G,B) 255 (W,R,G,B)		VXX: EBBS1=000, 000, 000, 000 VXX: EBBS1=255, 255, 255, 255	QVX: EBBS1	EBBS1=000, 000, 000, 000 EBBS1=255, 255, 255, 255	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT	0 (W,R,G,B) 255 (W,R,G,B)		VXX: EBBS2=000, 000, 000, 000 VXX: EBBS2=255, 255, 255, 255	QVX: EBBS2	EBBS2=000, 000, 000, 000 EBBS2=255, 255, 255, 255	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT	0 (W,R,G,B) 255 (W,R,G,B)		VXX: EBBS3=000, 000, 000, 000 VXX: EBBS3=255, 255, 255, 255	QVX: EBBS3	EBBS3=000, 000, 000, 000 EBBS3=255, 255, 255, 255	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER	OFF ON		VXX: EBI I 3=+00000 VXX: EBI I 3=+00001	QVX: EBI I 3	EBI I 3=+00000 EBI I 3=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER	OFF ON		VXX: EBI I 4=+00000 VXX: EBI I 4=+00001	QVX: EBI I 4	EBI I 4=+00000 EBI I 4=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT INTERLOCKED	OFF ON		VXX: EBI I 5=+00000 VXX: EBI I 5=+00001	QVX: EBI I 5	EBI I 5=+00000 EBI I 5=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT	OFF ON		VXX: EBI I 6=+00000 VXX: EBI I 6=+00001	QVX: EBI I 6	EBI I 6=+00000 EBI I 6=+00001	✓ ✓	✓ ✓	
	EDGE BLENDING-AUTO TESTPATTERN	OFF ON		VXX: EATI 1=+00000 VXX: EATI 1=+00001	QVX: EATI 1	EATI 1=+00000 EATI 1=+00001	✓ ✓	✓ ✓	
	FRAME RESPONSE	NORMAL FAST		VXX: FDYI 0=+00000 VXX: FDYI 0=+00001	QVX: FDYI 0	FDYI 0=+00000 FDYI 0=+00001	✓ ✓	✓ ✓	
	RASTER POSITION-HORIZONTAL	-2048 +2047		VRH: 2952 VRH: 7047	QRH	2952 7047	✓ ✓	✓ ✓	
	RASTER POSITION-VERTICAL	-2048 +2047		VRV: 2952 VRV: 7047	QRV	2952 7047	✓ ✓	✓ ✓	
	DISPLAY LANGUAGE	LANGUAGE	English German French Spanish Italian Japanese Chinese Russian Korea Portuguse Swedish Norwegian Danish Polish Czech Hungarian Thai Dutch Finnish Romanian Turkish Arabic Kazakh Vietnamese		OLG: ENG OLG: DEU OLG: FRA OLG: ESP OLG: I TL OLG: JPN OLG: CHI OLG: RUS OLG: KOR OLG: POR OLG: SVE OLG: NOR OLG: DAN OLG: POL OLG: CES OLG: MAG OLG: THA OLG: NLD OLG: FI N OLG: RUM OLG: TUR OLG: ARA OLG: KAZ OLG: VI E	QLG	ENG DEU FRA ESP I TL JPN CHI RUS KOR POR SVE NOR DAN POL CES MAG THA NLD FI N RUM TUR ARA KAZ VI E	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓	✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓
		COLOR MATCHING	OFF		VXX: CMAI 0=+00000	QVX: CMAI 0	CMAI 0=+00000	✓	✓

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575
DISPLAY OPTION	RGB IN-RGB2 EDID RESOLUTION	SCREEB FIT		VXX: EDMI 1=+00001		EDMI 1=+00001	✓	✓
		USER		VXX: EDMI 1=+00010		EDMI 1=+00010	✓	✓
		1024x768p		VXX: EDRS1=1024: 0768: p	QVX: EDRS1	EDRS1=1024: 0768: p	✓	✓
		1280x720p		VXX: EDRS1=1280: 0720: p		EDRS1=1280: 0720: p	✓	✓
		1280x768p		VXX: EDRS1=1280: 0768: p		EDRS1=1280: 0768: p	✓	✓
		1280x800p		VXX: EDRS1=1280: 0800: p		EDRS1=1280: 0800: p	✓	✓
		1280x1024p		VXX: EDRS1=1280: 1024: p		EDRS1=1280: 1024: p	✓	✓
		1366x768p		VXX: EDRS1=1366: 0768: p		EDRS1=1366: 0768: p	✓	✓
		1400x1050p		VXX: EDRS1=1400: 1050: p		EDRS1=1400: 1050: p	✓	✓
		1440x900p		VXX: EDRS1=1440: 0900: p		EDRS1=1440: 0900: p	✓	✓
		1600x900p		VXX: EDRS1=1600: 0900: p		EDRS1=1600: 0900: p	✓	✓
		1600x1200p		VXX: EDRS1=1600: 1200: p		EDRS1=1600: 1200: p	✓	✓
		1680x1050p		VXX: EDRS1=1680: 1050: p		EDRS1=1680: 1050: p	✓	✓
		1920x1080p		VXX: EDRS1=1920: 1080: p		EDRS1=1920: 1080: p	✓	✓
	1920x1080i		VXX: EDRS1=1920: 1080: i		EDRS1=1920: 1080: i	✓	✓	
	1920x1200p		VXX: EDRS1=1920: 1200: p		EDRS1=1920: 1200: p	✓	✓	
	RGB IN-RGB2 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI 1=+06000	QVX: EDVI 1	EDVI 1=+06000	✓	✓
		50Hz		VXX: EDVI 1=+05000		EDVI 1=+05000	✓	✓
		48Hz		VXX: EDVI 1=+04800		EDVI 1=+04800	✓	✓
		30Hz		VXX: EDVI 1=+03000		EDVI 1=+03000	✓	✓
		25Hz		VXX: EDVI 1=+02500		EDVI 1=+02500	✓	✓
	24Hz		VXX: EDVI 1=+02400		EDVI 1=+02400	✓	✓	
	DVI-D IN-EDID	EDID1		OED: 1	QED	1	✓	✓
		EDID2(PC)		OED: 2		2	✓	✓
		EDID3		OED: 3		3	✓	✓
	DVI-D IN-SIGNAL LEVEL	0-255 PC		VXX: DVI I 0=+00000	QVX: DVI I 0	DVI I 0=+00000	✓	✓
		15-235		VXX: DVI I 0=+00001		DVI I 0=+00001	✓	✓
		AUTO		VXX: DVI I 0=+00002		DVI I 0=+00002	✓	✓
	DVI-D IN-EDID MODE	DEFAULT		VXX: EDMI 2=+00000	QVX: EDMI 0	EDMI 2=+00000	✓	✓
		SCREEN FIT		VXX: EDMI 2=+00001		EDMI 2=+00001	✓	✓
		USER		VXX: EDMI 2=+00010		EDMI 2=+00010	✓	✓
	DVI-D IN-EDID RESOLUTION	1024x768p		VXX: EDRS2=1024: 0768: p	QVX: EDRS2	EDRS2=1024: 0768: p	✓	✓
		1280x720p		VXX: EDRS2=1280: 0720: p		EDRS2=1280: 0720: p	✓	✓
		1280x768p		VXX: EDRS2=1280: 0768: p		EDRS2=1280: 0768: p	✓	✓
		1280x800p		VXX: EDRS2=1280: 0800: p		EDRS2=1280: 0800: p	✓	✓
		1280x1024p		VXX: EDRS2=1280: 1024: p		EDRS2=1280: 1024: p	✓	✓
		1366x768p		VXX: EDRS2=1366: 0768: p		EDRS2=1366: 0768: p	✓	✓
		1400x1050p		VXX: EDRS2=1400: 1050: p		EDRS2=1400: 1050: p	✓	✓
		1440x900p		VXX: EDRS2=1440: 0900: p		EDRS2=1440: 0900: p	✓	✓
		1600x900p		VXX: EDRS2=1600: 0900: p		EDRS2=1600: 0900: p	✓	✓
		1600x1200p		VXX: EDRS2=1600: 1200: p		EDRS2=1600: 1200: p	✓	✓
		1680x1050p		VXX: EDRS2=1680: 1050: p		EDRS2=1680: 1050: p	✓	✓
		1920x1080p		VXX: EDRS2=1920: 1080: p		EDRS2=1920: 1080: p	✓	✓
		1920x1080i		VXX: EDRS2=1920: 1080: i		EDRS2=1920: 1080: i	✓	✓
		1920x1200p		VXX: EDRS2=1920: 1200: p		EDRS2=1920: 1200: p	✓	✓
	DVI-D IN-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI 2=+06000	QVX: EDVI 2	EDVI 2=+06000	✓	✓
		50Hz		VXX: EDVI 2=+05000		EDVI 2=+05000	✓	✓
		48Hz		VXX: EDVI 2=+04800		EDVI 2=+04800	✓	✓
30Hz			VXX: EDVI 2=+03000		EDVI 2=+03000	✓	✓	
25Hz			VXX: EDVI 2=+02500		EDVI 2=+02500	✓	✓	
24Hz		VXX: EDVI 2=+02400		EDVI 2=+02400	✓	✓		
HDMI IN-EDID MODE	DEFAULT		VXX: EDMI 3=+00000	QVX: EDMI 3	EDMI 3=+00000	✓	✓	
	SCREEN FIT		VXX: EDMI 3=+00001		EDMI 3=+00001	✓	✓	
	USER		VXX: EDMI 3=+00010		EDMI 3=+00010	✓	✓	
HDMI IN-EDID RESOLUTION	1024x768p		VXX: EDRS3=1024: 0768: p	QVX: EDRS3	EDRS3=1024: 0768: p	✓	✓	
	1280x720p		VXX: EDRS3=1280: 0720: p		EDRS3=1280: 0720: p	✓	✓	
	1280x768p		VXX: EDRS3=1280: 0768: p		EDRS3=1280: 0768: p	✓	✓	
	1280x800p		VXX: EDRS3=1280: 0800: p		EDRS3=1280: 0800: p	✓	✓	
	1280x1024p		VXX: EDRS3=1280: 1024: p		EDRS3=1280: 1024: p	✓	✓	
	1366x768p		VXX: EDRS3=1366: 0768: p		EDRS3=1366: 0768: p	✓	✓	
	1400x1050p		VXX: EDRS3=1400: 1050: p		EDRS3=1400: 1050: p	✓	✓	
	1440x900p		VXX: EDRS3=1440: 0900: p		EDRS3=1440: 0900: p	✓	✓	
	1600x900p		VXX: EDRS3=1600: 0900: p		EDRS3=1600: 0900: p	✓	✓	
	1600x1200p		VXX: EDRS3=1600: 1200: p		EDRS3=1600: 1200: p	✓	✓	
	1680x1050p		VXX: EDRS3=1680: 1050: p		EDRS3=1680: 1050: p	✓	✓	
	1920x1080p		VXX: EDRS3=1920: 1080: p		EDRS3=1920: 1080: p	✓	✓	
	1920x1080i		VXX: EDRS3=1920: 1080: i		EDRS3=1920: 1080: i	✓	✓	
	1920x1200p		VXX: EDRS3=1920: 1200: p		EDRS3=1920: 1200: p	✓	✓	
HDMI IN-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI 3=+06000	QVX: EDVI 3	EDVI 3=+06000	✓	✓	
	50Hz		VXX: EDVI 3=+05000		EDVI 3=+05000	✓	✓	
	48Hz		VXX: EDVI 3=+04800		EDVI 3=+04800	✓	✓	
	30Hz		VXX: EDVI 3=+03000		EDVI 3=+03000	✓	✓	
	25Hz		VXX: EDVI 3=+02500		EDVI 3=+02500	✓	✓	
24Hz		VXX: EDVI 3=+02400		EDVI 3=+02400	✓	✓		
HDMI IN-HDMI1 SIGNAL LEVEL	0-1023		VXX: HSLI 1=+00000	QVX: HSLI 1	HSLI 1=+00000	✓	✓	
	64-940		VXX: HSLI 1=+00001		HSLI 1=+00001	✓	✓	
	AUTO		VXX: HSLI 1=+00002		HSLI 1=+00002	✓	✓	
HDMI IN-HDMI2 SIGNAL LEVEL	0-1023		VXX: HSLI 2=+00000	QVX: HSLI 2	HSLI 2=+00000	✓	✓	
	64-940		VXX: HSLI 2=+00001		HSLI 2=+00001	✓	✓	
	AUTO		VXX: HSLI 2=+00002		HSLI 2=+00002	✓	✓	
HDMI IN-HDMI2 EDID MODE	DEFAULT		VXX: EDMI 6=+00000	QVX: EDMI 3	EDMI 6=+00000	✓	✓	
	SCREEN FIT		VXX: EDMI 6=+00001		EDMI 6=+00001	✓	✓	
	USER		VXX: EDMI 6=+00010		EDMI 6=+00010	✓	✓	
HDMI IN-HDMI2 EDID RESOLUTION	1024x768p		VXX: EDRS6=1024: 0768: p	QVX: EDRS3	EDRS6=1024: 0768: p	✓	✓	
	1280x720p		VXX: EDRS6=1280: 0720: p		EDRS6=1280: 0720: p	✓	✓	
	1280x768p		VXX: EDRS6=1280: 0768: p		EDRS6=1280: 0768: p	✓	✓	
	1280x800p		VXX: EDRS6=1280: 0800: p		EDRS6=1280: 0800: p	✓	✓	
	1280x1024p		VXX: EDRS6=1280: 1024: p		EDRS6=1280: 1024: p	✓	✓	
	1366x768p		VXX: EDRS6=1366: 0768: p		EDRS6=1366: 0768: p	✓	✓	
	1400x1050p		VXX: EDRS6=1400: 1050: p		EDRS6=1400: 1050: p	✓	✓	
	1440x900p		VXX: EDRS6=1440: 0900: p		EDRS6=1440: 0900: p	✓	✓	
	1600x900p		VXX: EDRS6=1600: 0900: p		EDRS6=1600: 0900: p	✓	✓	
	1600x1200p		VXX: EDRS6=1600: 1200: p		EDRS6=1600: 1200: p	✓	✓	
	1680x1050p		VXX: EDRS6=1680: 1050: p		EDRS6=1680: 1050: p	✓	✓	
	1920x1080p		VXX: EDRS6=1920: 1080: p		EDRS6=1920: 1080: p	✓	✓	
	1920x1080i		VXX: EDRS6=1920: 1080: i		EDRS6=1920: 1080: i	✓	✓	
	1920x1200p		VXX: EDRS6=1920: 1200: p		EDRS6=1920: 1200: p	✓	✓	
HDMI IN-HDMI2 EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI 6=+06000	QVX: EDVI 3	EDVI 6=+06000	✓	✓	
	50Hz		VXX: EDVI 6=+05000		EDVI 6=+05000	✓	✓	
	48Hz		VXX: EDVI 6=+04800		EDVI 6=+04800	✓	✓	
	30Hz		VXX: EDVI 6=+03000		EDVI 6=+03000	✓	✓	
	25Hz		VXX: EDVI 6=+02500		EDVI 6=+02500	✓	✓	
24Hz		VXX: EDVI 6=+02400		EDVI 6=+02400	✓	✓		
DIGITAL LINK-SIGNAL LEVEL	AUTO		VXX: DKLI 1=+00000	QVX: DKLI 1	DKLI 1=+00000	✓	✓	
	0-1023		VXX: DKLI 1=+00001		DKLI 1=+00001	✓	✓	
	64-940		VXX: DKLI 1=+00002		DKLI 1=+00002	✓	✓	
DIGITAL LINK-EDID MODE	DEFAULT		VXX: EDMI 4=+00000	QVX: EDMI 4	EDMI 4=+00000	✓	✓	
	SCREEN FIT		VXX: EDMI 4=+00001		EDMI 4=+00001	✓	✓	
	USER		VXX: EDMI 4=+00010		EDMI 4=+00010	✓	✓	
DIGITAL LINK-EDID RESOLUTION	1024x768p		VXX: EDRS4=1024: 0768: p	QVX: EDRS4	EDRS4=1024: 0768: p	✓	✓	
	1280x720p		VXX: EDRS4=1280: 0720: p		EDRS4=1280: 0720: p	✓	✓	
	1280x768p		VXX: EDRS4=1280: 0768: p		EDRS4=1280: 0768: p	✓	✓	
	1280x800p		VXX: EDRS4=1280: 0800: p		EDRS4=1280: 0800: p	✓	✓	
1280x1024p		VXX: EDRS4=1280: 1024: p		EDRS4=1280: 1024: p	✓	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575
		1366x768p		VXX: EDRS4=1366: 0768: p		EDRS4=1366: 0768: p	✓	✓
		1400x1050p		VXX: EDRS4=1400: 1050: p		EDRS4=1400: 1050: p	✓	✓
		1440x900p		VXX: EDRS4=1440: 0900: p		EDRS4=1440: 0900: p	✓	✓
		1600x900p		VXX: EDRS4=1600: 0900: p		EDRS4=1600: 0900: p	✓	✓
		1600x1200p		VXX: EDRS4=1600: 1200: p		EDRS4=1600: 1200: p	✓	✓
		1680x1050p		VXX: EDRS4=1680: 1050: p		EDRS4=1680: 1050: p	✓	✓
		1920x1080p		VXX: EDRS4=1920: 1080: p		EDRS4=1920: 1080: p	✓	✓
		1920x1080i		VXX: EDRS4=1920: 1080: i		EDRS4=1920: 1080: i	✓	✓
		1920x1200p		VXX: EDRS4=1920: 1200: p		EDRS4=1920: 1200: p	✓	✓
	DIGITAL LINK-EDID VERTICAL SCAN FREQUENCY	60Hz		VXX: EDVI 4=+06000	QVX: EDVI 4	EDVI 4=+06000	✓	✓
		50Hz		VXX: EDVI 4=+05000		EDVI 4=+05000	✓	✓
		48Hz		VXX: EDVI 4=+04800		EDVI 4=+04800	✓	✓
		30Hz		VXX: EDVI 4=+03000		EDVI 4=+03000	✓	✓
		25Hz		VXX: EDVI 4=+02500		EDVI 4=+02500	✓	✓
		24Hz		VXX: EDVI 4=+02400		EDVI 4=+02400	✓	✓
	INPUT GUIDE	OFF		OI D: 0	QDI	0	✓	✓
		ON (SIMPLE)		OI D: 1		1	✓	✓
	OSD POSITION	UPPER LEFT		ODP: 1	QDP	1	✓	✓
		CETRE LEFT		ODP: 2		2	✓	✓
		LOWER LEFT		ODP: 3		3	✓	✓
		TOP CENTER		ODP: 4		4	✓	✓
		CENTER		ODP: 5		5	✓	✓
		LOEER CENTER		ODP: 6		6	✓	✓
		UPPER RIGHT		ODP: 7		7	✓	✓
		CENTER RIGHT		ODP: 8		8	✓	✓
		LOWER RIGHT		ODP: 9		9	✓	✓
	OSD ROTATION	OFF		VXX: OSRI 1=+00000	QVX: OSRI 1	OSRI 1=+00000	✓	✓
		CLOCKWISE		VXX: OSRI 1=+00001		OSRI 1=+00001	✓	✓
		COUNTER CLOCKWISE		VXX: OSRI 1=+00002		OSRI 1=+00002	✓	✓
	OSD MEMORY	OFF		VXX: OMYI 0=+00000	QVX: OMYI 0	OMYI 0=+00000	✓	✓
		ON		VXX: OMYI 0=+00001		OMYI 0=+00001	✓	✓
	ON SCREEN	OFF		OOS: 0	QOS	0	✓	✓
		ON		OOS: 1		1	✓	✓
	WARNING MESSAGE	OFF		VXX: WMDI 0=+00000	QVX: WMDI 0	WMDI 0=+00000	✓	✓
		ON		VXX: WMDI 0=+00001		WMDI 0=+00001	✓	✓
	OSD DESIGN	1(YELLOW)		MOD: 0	QOD	0	✓	✓
		2(BLUE)		MOD: 1		1	✓	✓
		3(WHITE)		MOD: 2		2	✓	✓
		4(GREEN)		MOD: 3		3	✓	✓
		5(PEACH)		MOD: 4		4	✓	✓
		6(BROWN)		MOD: 5		5	✓	✓
	CLOSED CAPTION SETTING	OFF		OCC: 0	QCC	0	✓	✓
		CC1		OCC: 1		1	✓	✓
		CC2		OCC: 2		2	✓	✓
		CC3		OCC: 3		3	✓	✓
		CC4		OCC: 4		4	✓	✓
	IMAGE ROTATION	OFF		VXX: I ROI 1=+00000	QVX: I ROI 1	I ROI 1=+00000	✓	✓
		CLOCKWISE		VXX: I ROI 1=+00001		I ROI 1=+00001	✓	✓
		COUNTER CLOCKWISE		VXX: I ROI 1=+00002		I ROI 1=+00002	✓	✓
	SCREEN SETTING	16:10		VSF: 0	QSF	0	✓	✓
		16:9		VSF: 1		1	✓	✓
		4:3		VSF: 2		2	✓	✓
	SCREEN POSITION-VERTICAL	min.		VXX: VSPI 0=-00120	QVX: VSPI 0	VSPI 0=-00120	-60	-60
		max.		VXX: VSPI 0=+00120		VSPI 0=+00120	60	60
	SCREEN POSITION-HORZONTAL	min.		VXX: HSPI 0=-00320	QVX: HSPI 0	HSPI 0=-00320	-160	-160
		max.		VXX: HSPI 0=+00320		HSPI 0=+00320	+160	+160
	STARTUP LOGO	OFF		MLO: 0	QLO	0	✓	✓
		USER LOGO		MLO: 1		1	✓	✓
		DEFAULT LOGO		MLO: 2		2	✓	✓
	UNIFORMITY-PC CORRECTION *	OFF		VXX: UFMI 1=+00000	QVX: UFMI 1	UFMI 1=+00000	✓	✓
		ON		VXX: UFMI 1=+00001		UFMI 1=+00001	✓	✓
	UNIFORMITY-WHITE/RED/GREEN/RED	* PARAMETER		ESW: *, ****, ****, **	ESR: *, **	** , ****, ****	✓	✓
		* PARAMETER 1	WHITE	ESW: W, ****, ****, **	ESR: W, **	** , ****, ****	✓	✓
			RED	ESW: R, ****, ****, **	ESR: R, **	** , ****, ****	✓	✓
			GREEN	ESW: G, ****, ****, **	ESR: G, **	** , ****, ****	✓	✓
			BLUE	ESW: B, ****, ****, **	ESR: B, **	** , ****, ****	✓	✓
		* PARAMETER 2	VERTICAL(-127)	ESW: *, -127, ****, **	ESR: *, **	** , -127, ****	✓	✓
			VERTICAL(+127)	ESW: *, +127, ****, **	ESR: *, **	** , +127, ****	✓	✓
		* PARAMETER 3	HORIZONTAL(-127)	ESW: *, ****, -127, **	ESR: *, **	** , ****, -127	✓	✓
			HORIZONTAL(+127)	ESW: *, ****, +127, **	ESR: *, **	** , ****, +127	✓	✓
		* PARAMETER 4	L1(OFF)	ESW: *, ****, ****, 0*	ESR: *, 0*	0*, ****, ****	✓	✓
			L1(ON)	ESW: *, ****, ****, 1*	ESR: *, 1*	1*, ****, ****	✓	✓
			L2(OFF)	ESW: *, ****, ****, *0	ESR: *, *0	*0, ****, ****	✓	✓
			L2(ON)	ESW: *, ****, ****, *1	ESR: *, *1	*1, ****, ****	✓	✓
	SHUTTER SETTING-FADE IN	0.0s(OFF)		VXX: SEFS1=0. 0	QVX: SEFS1	SEFS1=0. 0	✓	✓
		0.5s		VXX: SEFS1=0. 5		SEFS1=0. 5	✓	✓
		1.0s		VXX: SEFS1=1. 0		SEFS1=1. 0	✓	✓
		1.5s		VXX: SEFS1=1. 5		SEFS1=1. 5	✓	✓
		2.0s		VXX: SEFS1=2. 0		SEFS1=2. 0	✓	✓
		2.5s		VXX: SEFS1=2. 5		SEFS1=2. 5	✓	✓
		3.0s		VXX: SEFS1=3. 0		SEFS1=3. 0	✓	✓
		3.5s		VXX: SEFS1=3. 5		SEFS1=3. 5	✓	✓
		4.0s		VXX: SEFS1=4. 0		SEFS1=4. 0	✓	✓
		5.0s		VXX: SEFS1=5. 0		SEFS1=5. 0	✓	✓
		7.0s		VXX: SEFS1=7. 0		SEFS1=7. 0	✓	✓
		10.0s		VXX: SEFS1=10. 0		SEFS1=10. 0	✓	✓
	SHUTTER SETTING-FADE OUT	0.0s(OFF)		VXX: SEFS2=0. 0	QVX: SEFS2	SEFS2=0. 0	✓	✓
		0.5s		VXX: SEFS2=0. 5		SEFS2=0. 5	✓	✓
		1.0s		VXX: SEFS2=1. 0		SEFS2=1. 0	✓	✓
		1.5s		VXX: SEFS2=1. 5		SEFS2=1. 5	✓	✓
		2.0s		VXX: SEFS2=2. 0		SEFS2=2. 0	✓	✓
		2.5s		VXX: SEFS2=2. 5		SEFS2=2. 5	✓	✓
		3.0s		VXX: SEFS2=3. 0		SEFS2=3. 0	✓	✓
		3.5s		VXX: SEFS2=3. 5		SEFS2=3. 5	✓	✓
		4.0s		VXX: SEFS2=4. 0		SEFS2=4. 0	✓	✓
		5.0s		VXX: SEFS2=5. 0		SEFS2=5. 0	✓	✓
		7.0s		VXX: SEFS2=7. 0		SEFS2=7. 0	✓	✓
		10.0s		VXX: SEFS2=10. 0		SEFS2=10. 0	✓	✓
	SHUTTER SETTING-STARTUP	OPEN		VXX: SEFI 3=+00000	QVX: SEFI 3	SEFI 3=+00000	✓	✓
		CLOSE		VXX: SEFI 3=+00001		SEFI 3=+00001	✓	✓
	BACK COLOR	BLUE		OBC: 0	QBC	0	✓	✓
		BLACK		OBC: 1		1	✓	✓
		USER LOGO		OBC: 2		2	✓	✓
		DEFAULT LOGO		OBC: 3		3	✓	✓
	WAVEFORM MONITOR	OFF		OWM: 0	QWM	0	✓	✓
		LUMINANCE		OWM: 5		5	✓	✓
		RED		OWM: 6		6	✓	✓
		GREEN		OWM: 7		7	✓	✓
		BLUE		OWM: 8		8	✓	✓
	WAVEFORM MONITOR-LINE ADJ.	0		VXX: WMLI 0=+00000	QVX: WMLI 0	WMLI 0=+00000	✓	✓
		+2159		VXX: WMLI 0=+02159		WMLI 0=+02159	✓	✓
	CUT OFF-RED	OFF		VXX: CUTI 1=+00000	QVX: CUTI 1	CUTI 1=+00000	✓	✓
		ON		VXX: CUTI 1=+00001		CUTI 1=+00001	✓	✓
	CUT OFF-GREEN	OFF		VXX: CUTI 2=+00000	QVX: CUTI 2	CUTI 2=+00000	✓	✓

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		RZ570 SERIES		
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575	
	CUT OFF-BLUE	ON		VXX: CUTI 2=+00001		CUTI 2=+00001		✓	✓
		OFF		VXX: CUTI 3=+00000	QVX: CUTI 3	CUTI 3=+00000		✓	✓
	ON		VXX: CUTI 3=+00001		CUTI 3=+00001		✓	✓	
	COMPUTER1 INPUT/OUTPUT	RGB/YBPBR Y/C		VXX: RYCI 1=+00000 VXX: RYCI 1=+00001	QVX: RYCI 1	RYCI 1=+00000 RYCI 1=+00001		✓	✓
	COMPUTER2 INOUT/OUTPUT SELECT	COMPUTER2 IN COMPUTER2 OUT		ORI : 2I N ORI : 20U	QRI	2I N 20U		✓	✓
	PROJECTOR ID	0(ALL) 64		RI S: 00 RI S: 64				✓	✓
	PROJECTION METHOD INSTALLATION	FRONT/DESK		OI L: 0	QSP	0		✓	✓
		REAR/DESK		OI L: 1		1		✓	✓
		FRONT/CEILING		OI L: 2		2		✓	✓
		REAR/CEILING		OI L: 3		3		✓	✓
		FRONT/AUTO REAR/AUTO		OI L: 4 OI L: 5		4 5		✓	✓
	PROJECTION METHOD(AUTO)	FRONT/DESK			QVX: PJMI 2	PJMI 2=+00000		✓	✓
		REAR/DESK				PJMI 2=+00001		✓	✓
		FRONT/CEILING				PJMI 2=+00002		✓	✓
		REAR/CEILING				PJMI 2=+00003		✓	✓
	AUTO COOLING CONDITION- STATUS	FLOOR			QVX: ADRI 1	ADRI 1=+00000		✓	✓
		CEILING				ADRI 1=+00001		✓	✓
		VERTICAL UP				ADRI 1=+00002		✓	✓
		VERTICAL DOWN				ADRI 1=+00003		✓	✓
	HIGH ALTITUDE MODE	Under 2700m(OFF)		OFM: 0	QFM	0		✓	✓
		Over 2700m(ON)		OFM: 1		1		✓	✓
	OPERATING MODE	NORMAL		VXX: OPEI 1=+00000	QVX: OPEI 1	OPEI 1=+00000		✓	✓
		ECO		VXX: OPEI 1=+00001		OPEI 1=+00001		✓	✓
		SILENT		VXX: OPEI 1=+00002		OPEI 1=+00002		✓	✓
		LONG LIFE1		VXX: OPEI 1=+00011		OPEI 1=+00011		✓	✓
		LONG LIFE2		VXX: OPEI 1=+00012		OPEI 1=+00012		✓	✓
		LONG LIFE3		VXX: OPEI 1=+00013		OPEI 1=+00013		✓	✓
		USER1(USER)		VXX: OPEI 1=+00101		OPEI 1=+00101		✓	✓
		USER2		VXX: OPEI 1=+00102		OPEI 1=+00102		✓	✓
		USER3		VXX: OPEI 1=+00103		OPEI 1=+00103		✓	✓
		LIGHT OUTPUT	min. max.		VXX: LOPI 2=+00050 VXX: LOPI 2=+01000	QVX: LOPI 2	LOPI 2=+00050 LOPI 2=+01000	20% 100%	5% 100%
	MAX LIGHT OUTPUT	min. max.		VXX: LOPI 3=+00050 VXX: LOPI 3=+01000	QVX: LOPI 3	LOPI 3=+00050 LOPI 3=+01000		5% 100%	
		ECO MANAGEMENT-AUTO POWER SAVE	OFF ON	VXX: ECOI 0=+00000 VXX: ECOI 0=+00001	QVX: ECOI 0	ECOI 0=+00000 ECOI 0=+00001		✓	✓
	ECO MANAGEMENT-AMBIENT LIGHT DETECTION	OFF ON		VXX: ECOI 1=+00000 VXX: ECOI 1=+00001	QVX: ECOI 1	ECOI 1=+00000 ECOI 1=+00001		✓	✓
	BRIGHTNESS CONTROL-SETUP- CALIBRATION TIME	OFF		VXX: BTMI 1=+00000	QVX: BTMI 1	BTMI 1=+00000		✓	✓
		00:01		VXX: BTMI 1=+00001		BTMI 1=+00001		✓	✓
		23:59		VXX: BTMI 1=+02359		BTMI 1=+02359		✓	✓
		00:00		VXX: BTMI 1=+02400		BTMI 1=+02400		✓	✓
	BRIGHTNESS CONTROL-SETUP- CALIBRATION MESSAGE	OFF		VXX: BMGI 1=+00000	QVX: BMGI 1	BMGI 1=+00000		✓	✓
		ON		VXX: BMGI 1=+00001		BMGI 1=+00001		✓	✓
	BRIGHTNESS CONTROL-GAIN	20%		VXX: TGAI 0=+00020	QVX: TGAI 0	TGAI 0=+00020		✓	✓
		100%		VXX: TGAI 0=+00100		TGAI 0=+00100		✓	✓
	BRIGHTNESS CONTROL-SETUP- CONSTANT MODE	OFF		VXX: BCMI 0=+00000	QVX: BCMI 0	BCMI 0=+00000		✓	✓
		AUTO		VXX: BCMI 0=+00001		BCMI 0=+00001		✓	✓
		PC		VXX: BCMI 0=+00002		BCMI 0=+00002		✓	✓
BRIGHTNESS CONTROL-SETUP- LINK	OFF		VXX: BCLI 0=+00000	QVX: BCLI 0	BCLI 0=+00000		✓	✓	
	GROUP A		VXX: BCLI 0=+00001		BCLI 0=+00001		✓	✓	
	GROUP B		VXX: BCLI 0=+00002		BCLI 0=+00002		✓	✓	
	GROUP C		VXX: BCLI 0=+00003		BCLI 0=+00003		✓	✓	
	GROUP D		VXX: BCLI 0=+00004		BCLI 0=+00004		✓	✓	
BRIGHTNESS CONTROL-SETUP APPLY STANDBY MODE	APPLY		VXX: BCSI 0=+00001				✓	✓	
QUICK STARTUP	NORMAL		VXX: STMI 0=+00000	QVX: STMI 0	STMI 0=+00000		✓	✓	
	ECO		VXX: STMI 0=+00003		STMI 0=+00003		✓	✓	
QUICK STARTUP-VALID PERIOD	OFF		VXX: QSUI 1=+00000	QVX: QSUI 1	QSUI 1=+00000		✓	✓	
	ON		VXX: QSUI 1=+00001		QSUI 1=+00001		✓	✓	
SCHEDULE	30MIN.		VXX: QSUI 2=+00030	QVX: QSUI 2	QSUI 2=+00030		✓	✓	
	60MIN.		VXX: QSUI 2=+00060		QSUI 2=+00060		✓	✓	
	90MIN.		VXX: QSUI 2=+00090		QSUI 2=+00090		✓	✓	
SCHEDULE-PROGRAM ASSIGN	OFF		VXX: SPGI *+=+00000	QVX: SPGI *	SPGI *+=+00000		✓	✓	
	PROGRAM1		VXX: SPGI *+=+00001		SPGI *+=+00001		✓	✓	
PROGRAM2		VXX: SPGI *+=+00002		SPGI *+=+00002		✓	✓		
PROGRAM3		VXX: SPGI *+=+00003		SPGI *+=+00003		✓	✓		
PROGRAM4		VXX: SPGI *+=+00004		SPGI *+=+00004		✓	✓		
PROGRAM5		VXX: SPGI *+=+00005		SPGI *+=+00005		✓	✓		
PROGRAM6		VXX: SPGI *+=+00006		SPGI *+=+00006		✓	✓		
PROGRAM7		VXX: SPGI *+=+00007		SPGI *+=+00007		✓	✓		
* PARAMETER	SUN		VXX: SPGI 0=+0000*	QVX: SPGI 0	SPGI 0=+0000*		✓	✓	
	MON		VXX: SPGI 1=+0000*	QVX: SPGI 1	SPGI 1=+0000*		✓	✓	
	TUE		VXX: SPGI 2=+0000*	QVX: SPGI 2	SPGI 2=+0000*		✓	✓	
	WED		VXX: SPGI 3=+0000*	QVX: SPGI 3	SPGI 3=+0000*		✓	✓	
	THU		VXX: SPGI 4=+0000*	QVX: SPGI 4	SPGI 4=+0000*		✓	✓	
	FRI		VXX: SPGI 5=+0000*	QVX: SPGI 5	SPGI 5=+0000*		✓	✓	
	SAT		VXX: SPGI 6=+0000*	QVX: SPGI 6	SPGI 6=+0000*		✓	✓	
SCHEDULE-COMMAND SETTING	COMMAND Del		VXX: SCCS*==*00****	QVX: SCCS*==**	SCCS*==*00****		✓	✓	
	STANDBY		VXX: SCCS*==*10****		SCCS*==*10****		✓	✓	
	POWER ON		VXX: SCCS*==*11****		SCCS*==*11****		✓	✓	
	SHUTTER OPEN		VXX: SCCS*==*20****		SCCS*==*20****		✓	✓	
	SHUTTER CLOSE		VXX: SCCS*==*21****		SCCS*==*21****		✓	✓	
	RGB1 INPUT		VXX: SCCS*==*31****		SCCS*==*31****		✓	✓	
	RGB2 INPUT		VXX: SCCS*==*32****		SCCS*==*32****		✓	✓	
	VIDEO INPUT		VXX: SCCS*==*41****		SCCS*==*41****		✓	✓	
	DVI-D INPUT		VXX: SCCS*==*51****		SCCS*==*51****		✓	✓	
	HDMI1 INPUT		VXX: SCCS*==*53****		SCCS*==*53****		✓	✓	
	HDMI2 INPUT		VXX: SCCS*==*54****		SCCS*==*54****		✓	✓	
	NORMAL		VXX: SCCS*==*70****		SCCS*==*70****		✓	✓	
	ECO		VXX: SCCS*==*71****		SCCS*==*71****		✓	✓	
	LONG LIFE1		VXX: SCCS*==*72****		SCCS*==*72****		✓	✓	
	LONG LIFE2		VXX: SCCS*==*73****		SCCS*==*73****		✓	✓	
	LONG LIFE3		VXX: SCCS*==*74****		SCCS*==*74****		✓	✓	
	USER1(USER)		VXX: SCCS*==*75****		SCCS*==*75****		✓	✓	
	USER2		VXX: SCCS*==*76****		SCCS*==*76****		✓	✓	
	USER3		VXX: SCCS*==*77****		SCCS*==*77****		✓	✓	
	SILENT		VXX: SCCS*==*78****		SCCS*==*78****		✓	✓	
	DIGITAL LINK		VXX: SCCS*==*B0****		SCCS*==*B0****		✓	✓	
INPUT 1		VXX: SCCS*==*B1****		SCCS*==*B1****		✓	✓		
INPUT 2		VXX: SCCS*==*B2****		SCCS*==*B2****		✓	✓		
INPUT 3		VXX: SCCS*==*B3****		SCCS*==*B3****		✓	✓		
INPUT 4		VXX: SCCS*==*B4****		SCCS*==*B4****		✓	✓		
INPUT 5		VXX: SCCS*==*B5****		SCCS*==*B5****		✓	✓		
INPUT 6		VXX: SCCS*==*B6****		SCCS*==*B6****		✓	✓		
INPUT 7		VXX: SCCS*==*B7****		SCCS*==*B7****		✓	✓		
INPUT 8		VXX: SCCS*==*B8****		SCCS*==*B8****		✓	✓		
INPUT 9		VXX: SCCS*==*B9****		SCCS*==*B9****		✓	✓		
INPUT 10		VXX: SCCS*==*BA****		SCCS*==*BA****		✓	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		RZ570 SERIES			
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575		
PROJECTOR SETUP	AUDIO IN STANDBY OFF			VXX: SCCS**A0****		SCCS**A0****		✓	✓	
	AUDIO IN STANDBY ON			VXX: SCCS**A1****		SCCS**A1****		✓	✓	
	QUICK STARTUP OFF			VXX: SCCS**A2****		SCCS**A2****		✓	✓	
	QUICK STARTUP ON			VXX: SCCS**A3****		SCCS**A3****		✓	✓	
	AUDIO VOLUME	0		VXX: SCCS**C0****		SCCS**C0****		✓	✓	
		63		VXX: SCCS**FF****		SCCS**FF****		✓	✓	
	* PARAMETER1	PROGRAM1			VXX: SCCS1=*****	QVX: SCCS1=**	SCCS1=*****		✓	✓
		PROGRAM2			VXX: SCCS2=*****	QVX: SCCS2=**	SCCS2=*****		✓	✓
		PROGRAM3			VXX: SCCS3=*****	QVX: SCCS3=**	SCCS3=*****		✓	✓
		PROGRAM4			VXX: SCCS4=*****	QVX: SCCS4=**	SCCS4=*****		✓	✓
		PROGRAM5			VXX: SCCS5=*****	QVX: SCCS5=**	SCCS5=*****		✓	✓
		PROGRAM6			VXX: SCCS6=*****	QVX: SCCS6=**	SCCS6=*****		✓	✓
		PROGRAM7			VXX: SCCS7=*****	QVX: SCCS7=**	SCCS7=*****		✓	✓
	* PARAMETER2	COMMAND 1			VXX: SCCS*=01*****	QVX: SCCS*=01	SCCS*=01*****		✓	✓
		COMMAND 16			VXX: SCCS*=16*****	QVX: SCCS*=16	SCCS*=16*****		✓	✓
	* PARAMETER3	00:00			VXX: SCCS**0000		SCCS**0000		✓	✓
		23:59			VXX: SCCS**2359		SCCS**2359		✓	✓
	STARTUP INPUT SELECT	RGB1			VXX: SI SS1=RG1	QVX: SI SS1	SI SS1=RG1		✓	✓
		RGB2			VXX: SI SS1=RG2		SI SS1=RG2		✓	✓
		DVI-D			VXX: SI SS1=DVI		SI SS1=DVI		✓	✓
		HDMI1			VXX: SI SS1=HD1		SI SS1=HD1		✓	✓
HDMI2				VXX: SI SS1=HD2		SI SS1=HD2		✓	✓	
DIGITAL LINK				VXX: SI SS1=DL1		SI SS1=DL1		✓	✓	
SDI1				VXX: SI SS1=SD1		SI SS1=SD1		✓	✓	
LAST USED				VXX: SI SS1=LSU		SI SS1=LSU		✓	✓	
STARTUP INPUT SELECT (DIGITAL LINK)	LAST USED			VXX: SI SI 2=+00000	QVX: SI SI 2	SI SI 2=+00000		✓	✓	
	INPUT1			VXX: SI SI 2=+00001		SI SI 2=+00001		✓	✓	
	INPUT2			VXX: SI SI 2=+00002		SI SI 2=+00002		✓	✓	
	INPUT3			VXX: SI SI 2=+00003		SI SI 2=+00003		✓	✓	
	INPUT4			VXX: SI SI 2=+00004		SI SI 2=+00004		✓	✓	
	INPUT5			VXX: SI SI 2=+00005		SI SI 2=+00005		✓	✓	
	INPUT6			VXX: SI SI 2=+00006		SI SI 2=+00006		✓	✓	
	INPUT7			VXX: SI SI 2=+00007		SI SI 2=+00007		✓	✓	
	INPUT8			VXX: SI SI 2=+00008		SI SI 2=+00008		✓	✓	
	INPUT9			VXX: SI SI 2=+00009		SI SI 2=+00009		✓	✓	
	INPIT10			VXX: SI SI 2=+00010		SI SI 2=+00010		✓	✓	
NO SIGNAL SHUT-OFF	DISABLE			OAF: 00	QAF	00		✓	✓	
	10min			OAF: 10		10		✓	✓	
	20min			OAF: 20		20		✓	✓	
	30min			OAF: 30		30		✓	✓	
	40min			OAF: 40		40		✓	✓	
	50min			OAF: 50		50		✓	✓	
	60min			OAF: 60		60		✓	✓	
	70min			OAF: 70		70		✓	✓	
	80min			OAF: 80		80		✓	✓	
	90min			ODR: 90		90		✓	✓	
NO SIGNAL LIGHTS-OUT	DISABLE			VXX: SLOI 1=+00000	QVX: SLOI 1	SLOI 1=+00000		✓	✓	
	10SEC.			VXX: SLOI 1=+00010		SLOI 1=+00010		✓	✓	
	20SEC.			VXX: SLOI 1=+00020		SLOI 1=+00020		✓	✓	
	30SEC.			VXX: SLOI 1=+00030		SLOI 1=+00030		✓	✓	
	1MIN.			VXX: SLOI 1=+00060		SLOI 1=+00060		✓	✓	
	2MIN.			VXX: SLOI 1=+00120		SLOI 1=+00120		✓	✓	
	3MIN.			VXX: SLOI 1=+00180		SLOI 1=+00180		✓	✓	
5MIN.			VXX: SLOI 1=+00300		SLOI 1=+00300		✓	✓		
FUNCTION BUTTON	DISABLE			OFC: 0	QFC	0		✓	✓	
	SYSTEM SELECTOR			OFC: 1		1		✓	✓	
	SYSTEM DAYLIGHT VIEW			OFC: 2		2		✓	✓	
	SUB MEMORY			OFC: 3		3		✓	✓	
	WAVEFORM MONITOR			OFC: 6		6		✓	✓	
DATE AND TIME-DATE SETTING	Year: yyyy			TSD: 201506151	QGD	201506161		✓	✓	
	Month: mm			TSD: <i>yyyymmddw</i>		<i>yyyymmddw</i>		✓	✓	
	Date: dd							✓	✓	
DATE AND TIME-TIME SETTING	Hour: hh			TST: 154503	QGT	154503		✓	✓	
	Minute: mm			TST: <i>hmmss</i>		<i>hmmss</i>		✓	✓	
DATE AND TIME-NTP SYNCHRONIZATION	OFF			VXX: NTPI 0=+00000	QVX: NTPI 0	NTPI 0=+00000		✓	✓	
	ON			VXX: NTPI 0=+00001		NTPI 0=+00001		✓	✓	
LENS CALIBRATION	EXECUTE (ALL)			VXX: LNSI 0=+00001				✓	✓	
INITIALIZE-ALL USER DATA	USER INITIALIZE			VXX: RSTS1=0password				✓	✓	
	USER RESTORE			VXX: RSTS1=1password				✓	✓	
INITIAL START UP	STANDBY			OPY: 0	QPY	0		✓	✓	
	ON			OPY: 1		1		✓	✓	
	LAST MEMORY			OPY: 2		2		✓	✓	
AUDIO SETTING-VOLUME	0			AVL: 000	QAV	000		✓	✓	
	63			AVL: 063		063		✓	✓	
AUDIO SETTING-BALANCE	-16			ABL: -16	QBL	-16		✓	✓	
	16			ABL: 016		16		✓	✓	
AUDIO SETTING-IN STANDBY MODE	OFF			VXX: ASBI 0=+00000	QVX: ASBI 0	ASBI 0=+00000		✓	✓	
	ON			VXX: ASBI 0=+00001		ASBI 0=+00001		✓	✓	
AUDIO SETTING-IN SHUTTER MODE	OFF			VXX: ASHI 1=+00000	QVX: ASHI 1	ASHI 1=+00000		✓	✓	
	ON			VXX: ASHI 1=+00001		ASHI 1=+00001		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-COMPUTER1	AUDIO IN 1			VXX: AI NI 0=+00000	QVX: AI NI 0	AI NI 0=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 0=+00001		AI NI 0=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 0=+00002		AI NI 0=+00002		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-COMPUTER2	AUDIO IN 1			VXX: AI NI 1=+00000	QVX: AI NI 1	AI NI 1=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 1=+00001		AI NI 1=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 1=+00002		AI NI 1=+00002		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-HDMI1	HDMI1 AUDIO IN			VXX: AI NI 3=+00003	QVX: AI NI 3	AI NI 3=+00003		✓	✓	
	AUDIO IN 1			VXX: AI NI 3=+00000		AI NI 3=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 3=+00001		AI NI 3=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 3=+00002		AI NI 3=+00002		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-VIDEO	AUDIO IN 1			VXX: AI NI 4=+00000	QVX: AI NI 4	AI NI 4=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 4=+00001		AI NI 4=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 4=+00002		AI NI 4=+00002		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-HDMI2	HDMI2 AUDIO IN			VXX: AI NI 7=+00003	QVX: AI NI 7	AI NI 7=+00003		✓	✓	
	AUDIO IN 1			VXX: AI NI 7=+00000		AI NI 7=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 7=+00001		AI NI 7=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 7=+00002		AI NI 7=+00002		✓	✓	
AUDIO SETTING-AUDIO IN SELECT-DIGITAL LINK	DIGITAL LINK AUDIO IN			VXX: AI NI 8=+00005	QVX: AI NI 8	AI NI 8=+00005		✓	✓	
	AUDIO IN 1			VXX: AI NI 8=+00000		AI NI 8=+00000		✓	✓	
	AUDIO IN 2			VXX: AI NI 8=+00001		AI NI 8=+00001		✓	✓	
	AUDIO IN 3			VXX: AI NI 8=+00002		AI NI 8=+00002		✓	✓	
MODEL NAME	MODEL NAME			QID	MODELNAME		✓	✓		
SERIAL NUMBER	SW0101234			QSN	SW0101234		✓	✓		
PROJECTOR RUNTIME	7864320H			QVX: RTMS1	RTMS1=7864320		✓	✓		
LAMP1(LIGHT1) RUNTIME	9999H			Q\$L: 1	9999		✓	✓		
LIGHT1 RUNTIME	7864320H			QVX: LRTS3=00	LRTS3=00: 7864320		✓	✓		
LIGHT STATUS	ALL OFF			QLS	0		✓	✓		
	1:ON, 2:OFF				1		✓	✓		
LAMP(LIGHT) CONTROL STATUS	LAMP OFF			Q\$S	0		✓	✓		
	In turning ON				1		✓	✓		
	LAMP ON				2		✓	✓		
	LAMP Cooling				3		✓	✓		

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL		QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575	
P IN P	MAC ADDRESS	AB0102030405			QMA	AB0102030405		✓	✓
	MAIN FIRMWARE VERSION	V1.00.01			QVX: SVRS0	SVRS0=1. 00. 01		✓	✓
	SUB FIRMWARE VERSION	V1.00.01			QVX: SVRS2	SVRS2=1. 00. 01		✓	✓
	INPUT SIGNAL NAME	CHANNEL1 (MAIN CH) CHANNEL2 (SUB CH)			QVX: NSGS1 QVX: NSGS2	NSGS1=***** NSGS2=*****		✓	✓
	TEMPERATURE (INTAKE)	0030/0080			QTM: 0	0030/0080		✓	✓
	TEMPERATURE (EXHAUST AIR)	0030/0080			QTM: 1	0030/0080		✓	✓
	TEMPERATURE (OPTICS MODULE)	0030/0080			QTM: 2	0030/0080		✓	✓
	TEMPERATURE (LIGHT1 / LIGHT1-)	0030/0080			QTM: 11	0030/0080		✓	✓
	TEMPERATURE (LIGHT2 / LIGHT1-)	0030/0080			QTM: 12	0030/0080		✓	✓
	P IN P-MODE	OFF USER1 USER2 USER3		OPP: 0 OPP: 1 OPP: 2 OPP: 3	QPP	0 1 2 3		✓	✓
	P IN P-MAIN WINDOW	RGB1 RGB2 VIDEO DVI HDMI1 HDMI2 DIGITAL LINK		MSI : RG1 MSI : RG2 MSI : VI D MSI : DVI MSI : HD1 MSI : HD2 MSI : DL1	QIM	RG1 RG2 VI D DVI HD1 HD2 DL1		✓	✓
	P IN P-MAIN WINDOW-SIZE-INTERLOCKED	OFF ON		MSL: 0 MSL: 1				✓	✓
	P IN P-MAIN WINDOW-SIZE-VERTICAL	10 100		MSV: 010 MSV: 100				✓	✓
	P IN P-MAIN WINDOW-SIZE-HORIZONTAL	10 100		MSH: 010 MSH: 100				✓	✓
	P IN P-MAIN WINDOW-SIZE-BOTH	10 100		MSZ: 010 MSZ: 100				✓	✓
	P IN P-MAIN WINDOW-POSITION-VERTICAL	min. max.		MPV: -600 MPV: +600				-600 +600	-600 +600
P IN P-MAIN WINDOW-POSITION-HORIZONTAL	min. max.		MPH: -960 MPH: +960				-960 +960	-960 +960	
P IN P-MAIN WINDOW-SIZE	INTERLOCKED VERTICAL SIZE HORIZONTAL SIZE H/V SIZE	OFF ON 10-100 10-100		QSM	OF. V010. H010. HV100 ON. V010. H010. HV100 ** . V010. H*** . HV*** ** . V*** . H010. HV*** ** . V*** . H*** . HV100		✓	✓	
P IN P-MAIN WINDOW-POSITION	V:-364 +364 H:-651 +651			QPA	V-364. H-651 V+364. H+651		✓	✓	
P IN P-SUB WINDOW	RGB1 RGB2 VIDEO DVI HDMI1 HDMI2 DIGITAL LINK		SI S: RG1 SI S: RG2 SI S: VI D SI S: DVI SI S: HD1 SI S: HD2 SI S: DL1	QIS	RG1 RG2 VI D DVI HD1 HD2 DL1		✓	✓	
P IN P-SUB WINDOW-SIZE	INTERLOCKED VERTICAL SIZE HORIZONTAL SIZE H/V SIZE	OFF ON 10-100 10-100		QSS	OF. V010. H010. HV100 ON. V010. H010. HV100 ** . V010. H*** . HV*** ** . V*** . H010. HV*** ** . V*** . H*** . HV100		✓	✓	
P IN P-SUB WINDOW-POSITION	V:-364 +364 H:-651 +651			QPS	V-364. H-651 V+364. H+651		✓	✓	
P IN P-SUB WINDOW-SIZE-INTERLOCKED	OFF ON		SSL: 0 SSL: 1		0 1		✓	✓	
P IN P-SUB WINDOW-SIZE-VERTICAL	10 100		SSV: 010 SSV: 100		010 100		✓	✓	
P IN P-SUB WINDOW-SIZE-HORIZONTAL	10 100		SSH: 010 SSH: 100		010 100		✓	✓	
P IN P-SUB WINDOW-SIZE-BOTH	10 100		SSZ: 010 SSZ: 100		010 100		✓	✓	
P IN P-SUB WINDOW-POSITION-VERTICAL	-600 +600		SPV: -600 SPV: +600		-600 +600		-600 +600	-600 +600	
P IN P-SUB WINDOW-POSITION-HORIZONTAL	-960 +960		SPH: -960 SPH: +960		-960 +960		-960 +960	-960 +960	
P IN P-SUB WINDOW-CLOCK PHASE	0 31		VXX: SCPI 0=+00000 VXX: SCPI 0=+00031	QVX: SCPI 0	SCPI 0=+00000 SCPI 0=+00031		✓	✓	
P IN P-FRAME LOCK	MAIN WINDOW SUB WINDOW		PFL: 0 PFL: 1	QPF	0 1		✓	✓	
P IN P-TYPE	MAIN WINDOW SUB WINDOW		PTP: 0 PTP: 1	QPT	0 1		✓	✓	
TEST PATTERN	TEST PATTERN	Off White Black Window Reversed Window Color Bar V Convergence Color Bar Side 16:9/4:3 Focus Red Focus Green Focus Blue Focus Cyan Focus Magenta Focus Yellow	OTS: 00 OTS: 01 OTS: 02 OTS: 05 OTS: 06 OTS: 08 OTS: 11 OTS: 51 OTS: 59 OTS: 70 OTS: 71 OTS: 72 OTS: 73 OTS: 74 OTS: 75	QTS	00 01 02 05 06 08 11 51 59 70 71 72 73 74 75		✓	✓	
	SIGNAL LIST-REGISTRATION		OEM				✓	✓	
	SIGNAL LIST-DELETE	A1 A2 A7 A8 L1 L2 L7 L8		ODM: A1 ODM: A2 ODM: A7 ODM: A8 ODM: L1 ODM: L2 ODM: L7 ODM: L8				✓	✓
	SUB MEMORY LIST-CHANGEVER	01 96		OCS: 01 OCS: 96				✓	✓
	SUB MEMORY LIST-CHANGEVER (EXTENDED)	01 96		OCS: 01-01 OCS: 95-96				✓	✓
	SUB MEMORY LIST-REGISTRATION			OES				✓	✓
	SUB MEMORY LIST-DELETE	01 96		ODS: 01-01 ODS: 95-96				✓	✓
	SUB MEMORY USAGE STATE	01 96			QSB	01 96		✓	✓
	SECURITY	SECURITY SETTING	OFF ON		QVX: SPWI 1	SPWI 1=+00000 SPWI 1=+00001		✓	✓
	DIGITAL LINK MODE	DIGITAL LINK	AUTO	VXX: DKMI 1=+00001	QVX: DKMI 1	DKMI 1=+00001		✓	✓
		DIGITAL LINK	ETHERNET	VXX: DKMI 1=+00002		DKMI 1=+00002		✓	✓
		DIGITAL LINK	LONG REACH MODE	VXX: DKMI 1=+00003		DKMI 1=+00003		✓	✓
		DIGITAL LINK	LONG REACH MODE	VXX: DKMI 1=+00004		DKMI 1=+00004		✓	✓
		DIGITAL LINK-DUPLEX(Ethernet)	Auto negotiation 100BaseTX-Full 100BaseTX-Half		VXX: DKDI 1=+00000 VXX: DKDI 1=+00001 VXX: DKDI 1=+00002	QVX: DKDI 1	DKDI 1=+00000 DKDI 1=+00001 DKDI 1=+00002		✓

CATEGORY	FUNCTION	Parameter/Name	Sub-Parameter	CONTROL	QUERY		RZ570 SERIES	
				COMMANDS	COMMANDS	CALL BACK	RZ570	RZ575
NETWORK	DIGITAL LINK-DUPLEX(DIGITAL LINK)	Auto negotiation		VXX: DKDI 2=+00000	QVX: DKDI 2	DKDI 2=+00000	✓	✓
		100BaseTX-Full		VXX: DKDI 2=+00001		DKDI 2=+00001	✓	✓
		100BaseTX-Half		VXX: DKDI 2=+00002		DKDI 2=+00002	✓	✓
	DIGITAL LINK STATUS-LINK	NO LINK			QVX: DKSI 1	DKSI 1=+00000	✓	✓
		DIGITAL LINK				DKSI 1=+00001	✓	✓
		LPM				DKSI 1=+00002	✓	✓
		ETHERNET				DKSI 1=+00003	✓	✓
	DIGITAL LINK STATUS-HDCP STATUS	NO SIGNAL			QVX: DKSI 2	DKSI 2=+00000	✓	✓
		OFF				DKSI 2=+00001	✓	✓
		ON				DKSI 2=+00002	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MIN)	-255			QVX: DKSI 3	DKSI 3=-00255	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	0				DKSI 3=+00000	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	-255			QVX: DKSI 4	DKSI 4=-00255	✓	✓
	DIGITAL LINK STATUS-SIGNAL QUALITY (MAX)	0				DKSI 4=+00000	✓	✓
	DIGITAL LINK INPUT CH LIST	HD1:HDMI1,HD2:HDMI2...			QVX: DL1S1	DL1S1=HD1: HDMI 1, ****: ***	✓	✓
	PROJECTOR NAME SETTING	PROJECTOR1		VXX: NCGS8=PROJECTOR1	QVX: NCGS8	NCGS8=PROJECTOR1	✓	✓
	Art-Net SETUP	OFF		VXX: DANI 1=+00000	QVX: DANI 1	DANI 1=+00000	✓	✓
		ON(2.*.*)		VXX: DANI 1=+00002		DANI 1=+00002	✓	✓
		ON(10.*.*)		VXX: DANI 1=+00003		DANI 1=+00003	✓	✓
		ON(MANUAL)		VXX: DANI 1=+00004		DANI 1=+00004	✓	✓
Art-Net SETUP-START ADDRESS	1		VXX: DANI 3=+00001	QVX: DANI 3	DANI 3=+00001	✓	✓	
	501		VXX: DANI 3=+00501		DANI 3=+00501	✓	✓	
Art-Net SETUP-NET	0		VXX: DANI 4=+00000	QVX: DANI 4	DANI 4=+00000	✓	✓	
	127		VXX: DANI 4=+00127		DANI 4=+00127	✓	✓	
Art-Net SETUP-SUB NET	0		VXX: DANI 5=+00000	QVX: DANI 5	DANI 5=+00000	✓	✓	
	15		VXX: DANI 5=+00015		DANI 5=+00015	✓	✓	
Art-Net SETUP-UNIVERS	0		VXX: DANI 6=+00000	QVX: DANI 6	DANI 6=+00000	✓	✓	
	15		VXX: DANI 6=+00015		DANI 6=+00015	✓	✓	
Art-Net	OFF		VXX: DANI 7=+00000	QVX: DANI 7	DANI 7=+00000	✓	✓	
	WIRELESS LAN		VXX: DANI 7=+00011		DANI 7=+00011	✓	✓	
Art-Net SETUP-CHANNEL SETTING	DEFAULT		VXX: DANI 8=+00000	QVX: DANI 8	DANI 8=+00000	✓	✓	
	1		VXX: DANI 8=+00001		DANI 8=+00001	✓	✓	
	USER		VXX: DANI 8=+00100		DANI 8=+00100	✓	✓	
MIRRORING	MODERATOR		VXX: MI RI 1=+00001	QVX: MI RI 1	MI RI 1=+00001	✓	✓	
	MULTI		VXX: MI RI 1=+00002		MI RI 1=+00002	✓	✓	
	SINGLE		VXX: MI RI 1=+00004		MI RI 1=+00004	✓	✓	

Note: The commands or parameters with "*" shows available commands or parameters for the projector which has been activated by the Upgrade Kit.